

Charging System: Testing and Inspection

Pinpoint Tests

Test Note

CAUTION:

- ^ Do not make jumper connections except as directed. Incorrect connections may damage the voltage regulator test terminals, fuses, or fuse links.
- ^ Do not allow any metal object to come in contact with the generator housing and internal diode cooling fins.

NOTE:

- ^ While carrying out any pinpoint test, disregard any DTCs set while following any specific pinpoint test. After the completion of any test, be sure to clear all codes in the PCM.
- ^ All voltage measurements are referenced to the negative (-) battery post unless otherwise specified.




DIAGNOSIS AND TESTING (Continued)

PINPOINT TEST A: BATTERY IS DISCHARGED OR VOLTAGE IS LOW



CONDITIONS	DETAILS/RESULTS/ACTIONS
A1 CHECK BATTERY CONDITION	
	<p>1 Carry out the Battery—Condition Test to determine if the battery can hold a charge and is OK for use. Refer to Battery.</p> <ul style="list-style-type: none"> • Is the battery OK? <p>→ Yes GO to A2.</p> <p>→ No INSTALL a new battery. REFER to Battery. TEST the system for normal operation.</p>
A2 CHECK THE GENERATOR OUTPUT	
	<p>1 Carry out the On-Vehicle Generator Load/No Load Test. Refer to Component Tests.</p> <ul style="list-style-type: none"> • Is the generator OK? <p>→ Yes GO to A3.</p> <p>→ No GO to Pinpoint Test B.</p>
A3 CHECK FOR CURRENT DRAINS	
	<p>1 Carry out the Battery—Drain Test. Refer to Component Tests.</p> <ul style="list-style-type: none"> • Are there any excessive current drains? <p>→ Yes REPAIR as necessary. TEST the system for normal operation.</p> <p>→ No GO to A4.</p>
A4 CHECK FOR CURRENT DRAINS WHICH SHUT OFF WHEN THE BATTERY IS DISCONNECTED	
	<p>1 Carry out the Battery—Electronic Drains Which Shut Off When the Battery Cable is Disconnected Test. Refer to Component Tests.</p> <ul style="list-style-type: none"> • Are there any current drains which shut off when the battery is disconnected? <p>→ Yes REPAIR as necessary. TEST the system for normal operation.</p> <p>→ No GO to Pinpoint Test B.</p>

DIAGNOSIS AND TESTING (Continued)


PINPOINT TEST B: THE CHARGING SYSTEM WARNING INDICATOR IS ON WITH THE ENGINE RUNNING (THE SYSTEM VOLTAGE DOES NOT INCREASE)

CONDITIONS	DETAILS/RESULTS/ACTIONS
<p>B1 CHECK GENERATOR B+ CIRCUIT 36 (YE/WH)</p>  <p>A0006228</p>	<p>1 Measure the voltage between generator C102b, B+ terminal circuit 36 (YE/WH), component side and ground.</p> <ul style="list-style-type: none"> • Is the voltage equal to battery voltage (B+)? <p>→ Yes GO to B2.</p> <p>→ No REPAIR the circuit. TEST the system for normal operation.</p>
<p>B2 CHECK GENERATOR A CIRCUIT 112 (BK/YE)</p>  <p>A0013554</p>	<p>2 Measure the voltage between generator C102a pin 3, circuit 112 (BK/YE), harness side and ground.</p> <ul style="list-style-type: none"> • Is the voltage equal to battery positive voltage (B+)? <p>→ Yes GO to B3.</p> <p>→ No REPAIR the circuit. TEST the system for normal operation.</p>
<p>B3 CHECK I CIRCUIT 904 (LG/RD) FOR AN OPEN</p>  <p>Generator C102a</p>	<p>(Continued)</p>

DIAGNOSIS AND TESTING (Continued)**PINPOINT TEST B: THE CHARGING SYSTEM WARNING INDICATOR IS ON WITH THE ENGINE RUNNING (THE SYSTEM VOLTAGE DOES NOT INCREASE) (Continued)**

CONDITIONS	DETAILS/RESULTS/ACTIONS
<p>B3 CHECK I CIRCUIT 904 (LG/RD) FOR AN OPEN (Continued)</p> <p style="text-align: center;">3</p>  <p>A0006229</p>	<p>3 With the ignition switch in the RUN position and the engine off, measure the voltage between generator C102a pin 1, circuit 904 (LG/RD), harness side and ground.</p> <ul style="list-style-type: none"> • Is the voltage equal to battery positive voltage (B+)? <p>→ Yes GO to B4.</p> <p>→ No REPAIR the circuit. TEST the system for normal operation.</p>
<p>B4 CHECK FOR VOLTAGE DROP IN B+ CIRCUIT 36 (YE/WH)</p> <p style="text-align: center;">1</p>  <p>A0012310</p>	<p>2 With the engine at 2,000 rpm, measure the voltage drop between the generator C102b B+ terminal, circuit 36 (YE/WH), component side and positive battery terminal.</p> <ul style="list-style-type: none"> • Is the voltage drop less than 0.5 volt? <p>→ Yes INSTALL a new generator. REFER to Alternator. TEST the system for normal operation.</p> <p>→ No REPAIR high resistance in the B+ circuit 36 (YE/WH). TEST the system for normal operation.</p>


PINPOINT TEST D: THE SYSTEM OVERCHARGES (BATTERY VOLTAGE IS GREATER THAN 15.5 VOLTS)

CONDITIONS	DETAILS/RESULTS/ACTIONS
<p>D1 CHECK FOR VOLTAGE DROP IN A CIRCUIT 112 (BK/YE)</p>  <p>A0006234</p>	<p>3 Measure the voltage drop between generator C102a pin 3, circuit 112 (BK/YE), harness side and positive battery terminal.</p> <ul style="list-style-type: none"> • Is the voltage drop less than 0.5 volt? <p>→ Yes GO to D2.</p> <p>→ No REPAIR the high resistance in A circuit 112 (BK/YE). TEST the system for normal operation.</p>

(Continued)



D1

DIAGNOSIS AND TESTING (Continued)**PINPOINT TEST D: THE SYSTEM OVERCHARGES (BATTERY VOLTAGE IS GREATER THAN 15.5 VOLTS) (Continued)**


CONDITIONS	DETAILS/RESULTS/ACTIONS
<p>D2 CHECK GENERATOR AND BATTERY GROUND CONNECTIONS</p> 	<p>2 Check the ground connections between the voltage regulator, generator and engine, and the battery and engine.</p> <ul style="list-style-type: none"> • Are all good connections clean and tight? <p>→ Yes INSTALL a new generator. REFER to Alternator. TEST the system for normal operation.</p> <p>→ No REPAIR ground connections as necessary. TEST the system for normal operation.</p>

D2

PINPOINT TEST F: THE CHARGING SYSTEM WARNING INDICATOR IS ON WITH THE ENGINE RUNNING AND THE BATTERY INCREASES VOLTAGE

CONDITIONS	DETAILS/RESULTS/ACTIONS
F1 CHECK I CIRCUIT 904 (LG/RD) FOR A SHORT TO GROUND	
<div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  <p>Generator C102a</p> </div> <div style="text-align: center;">  </div> </div>	<div style="margin-top: 20px;"> <p>3 With the ignition switch in the RUN position, check the charging system warning indicator.</p> <ul style="list-style-type: none"> • Is the charging system warning indicator illuminated? <p>→ Yes REPAIR I circuit 904 (LG/RD) for a short to ground. TEST the system for normal operation.</p> <p>→ No INSTALL a new generator. REFER to Alternator. TEST the system for normal operation.</p> </div>

F1**PINPOINT TEST H: THE CHARGING SYSTEM WARNING INDICATOR IS OFF WITH THE IGNITION SWITCH IN THE RUN POSITION AND THE ENGINE OFF**

CONDITIONS	DETAILS/RESULTS/ACTIONS
H1 CHECK THE CHARGING SYSTEM WARNING INDICATOR LAMP	
<div style="text-align: center;">  <p>Generator C102a</p> </div>	

(Continued)

H1



DIAGNOSIS AND TESTING (Continued)**PINPOINT TEST H: THE CHARGING SYSTEM WARNING INDICATOR IS OFF WITH THE IGNITION SWITCH IN THE RUN POSITION AND THE ENGINE OFF (Continued)**

CONDITIONS	DETAILS/RESULTS/ACTIONS
<p data-bbox="198 220 776 247">H1 CHECK THE CHARGING SYSTEM WARNING INDICATOR LAMP (Continued)</p> <div data-bbox="292 262 649 577"> </div> <p data-bbox="224 613 311 634">A0006236</p> <div data-bbox="422 682 535 829"> </div>	<p data-bbox="782 262 1365 346">2 With the engine off, connect a fused (15A) jumper wire between the generator C102a pin 1, circuit 904 (LG/RD), harness side and ground.</p> <ul style="list-style-type: none"> <li data-bbox="836 850 1365 903">• Is the charging system warning indicator lamp illuminated? <li data-bbox="836 913 1365 1018">→ Yes INSTALL a new generator. REFER to Alternator. TEST the system for normal operation. <li data-bbox="836 1029 1365 1134">→ No REFER to Instrument Panel, Gauges and Warning Indicators for diagnosis and testing of the instrument cluster.

H1

DIAGNOSIS AND TESTING (Continued)

PINPOINT TEST J: THE CHARGING SYSTEM WARNING INDICATOR FLICKERS OR IS INTERMITTENT

CONDITIONS	DETAILS/RESULTS/ACTIONS
J1 CHECK FOR LOOSE CONNECTIONS	
	<p>1 Check all generator, battery, and power distribution connections for looseness, corrosion, loose or bent terminals, or loose eyelets.</p> <ul style="list-style-type: none"> • Are all connections clean and tight? <p>→ Yes GO to J2.</p> <p>→ No REPAIR as necessary. TEST the system for normal operation.</p>
J2 CHECK FUSES	
<p>1</p> 	<p>2 With the engine running, check BJB fuse 11 (15A) circuit 12 (BK/YE), for looseness by wiggling the fuse and noting the charging system warning indicator lamp operation.</p> <ul style="list-style-type: none"> • Does the charging system warning indicator lamp flicker? <p>→ Yes REPAIR loose fuse connections as necessary. TEST the system for normal operation.</p> <p>→ No GO to J3.</p>
J3 CHECK A CIRCUIT 112 (BK/YE) CONNECTIONS	
<p>1</p> 	

(Continued)

PINPOINT TEST L: THE GENERATOR IS NOISY






CONDITIONS	DETAILS/RESULTS/ACTIONS
L1 CHECK FOR ACCESSORY DRIVE NOISE	<p data-bbox="813 218 1391 327">1 Check the accessory drive belt for damage and correct installation. Check the accessory mounting brackets and generator pulley for looseness or misalignment.</p> <ul data-bbox="867 352 1179 380" style="list-style-type: none"> • Is the accessory drive OK? <p data-bbox="867 394 1024 443">→ Yes GO to L2.</p> <p data-bbox="867 457 1399 611">→ No REPAIR as necessary. REFER to Drive Belts, Mounts, Brackets and Accessories for diagnosis and testing of the accessory drive system. TEST the system for normal operation.</p>
L2 CHECK GENERATOR MOUNTING	<p data-bbox="813 684 1357 741">1 Check the generator mounting for loose bolts or misalignment.</p> <ul data-bbox="867 762 1271 789" style="list-style-type: none"> • Is the generator mounted correctly? <p data-bbox="867 814 1024 863">→ Yes GO to L3.</p> <p data-bbox="867 888 1373 970">→ No REPAIR as necessary. TEST the system for normal operation.</p>

(Continued)


L1 - L2

DIAGNOSIS AND TESTING (Continued)

PINPOINT TEST L: THE GENERATOR IS NOISY (Continued)

CONDITIONS	DETAILS/RESULTS/ACTIONS
<p>L3 CHECK GENERATOR FOR ELECTRICAL NOISE</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  <p>Generator C102a</p> </div> <div style="text-align: center;">  </div> </div>	<p>3 With the engine running, turn the headlights on, the rear defroster on, and the blower motor to the HI position.</p> <ul style="list-style-type: none"> • Is the noise still present? <p>→ Yes GO to L4.</p> <p>→ No INSTALL a new generator. REFER to Alternator. TEST the system for normal operation.</p>
<p>L4 CHECK GENERATOR FOR MECHANICAL NOISE</p> <div style="display: flex; justify-content: space-around; align-items: center;"> <div style="text-align: center;">  </div> <div style="text-align: center;">  <p>Generator C102a</p> </div> <div style="text-align: center;">  </div> </div>	<p>4 Turn all accessories OFF. With the engine running, use a stethoscope or equivalent listening device to probe the generator for unusual mechanical noise.</p> <ul style="list-style-type: none"> • Is the generator the noise source? <p>→ Yes INSTALL a new generator. REFER to Alternator. TEST the system for normal operation.</p> <p>→ No REFER to Engine to diagnose the source of engine noise.</p>

DIAGNOSIS AND TESTING (Continued)**PINPOINT TEST M: RADIO INTERFERENCE**

CONDITIONS	DETAILS/RESULTS/ACTIONS
M1 VERIFY GENERATOR IS SOURCE OF RADIO INTERFERENCE	
 <p>The diagram illustrates a five-step process for testing a generator for radio interference. Step 1 shows a radio dial with the needle pointing to 'M'. Step 2 shows a radio dial with the needle pointing to 'M'. Step 3 shows a radio dial with the needle pointing to 'M'. Step 4 shows a generator labeled 'Generator C102a' with a disconnected plug. Step 5 shows a radio dial with the needle pointing to 'M'.</p>	<p>2 With the engine running, tune the radio to a station where the interference is present.</p> <p>6 With the engine running, note any radio interference.</p> <ul style="list-style-type: none"> • Is the interference present with the generator disconnected? <p>→ Yes REFER to Radio, Stereo, and Compact Disc for diagnosis and testing of the in-vehicle entertainment system.</p> <p>→ No INSTALL a new generator. REFER to Alternator. TEST the system for normal operation.</p>

M1