


Transfer Case: Testing and Inspection Mechanical Shift on the Fly (MSOF)



Inspection and Verification




1. Verify the customer concern by operating the 2WD/4WD engagement.
2. Visually inspect the following for obvious signs of mechanical and electrical damage:
 - Switches
 - Fuse(s)
 - Damaged wiring harness
 - Loose or corroded connector(s)
 - Circuitry
3. If the concern is not visually evident, determine the symptom and proceed to the following Symptom Chart.




DTC	Circuit	Description	Test Mode
B1342	N/A	GEM Defective	On-Demand, Continuous
B1355	687 (GY/Y)	Ignition RUN Circuit Open or Short to Ground	On-Demand
B1359	297 (BK/LB)	Ignition RUN/ACC Circuit Open or Short to Ground	On-Demand, Continuous
B136	532 (R/LB)	Ignition START Circuit Short to Battery	On-Demand, Continuous
P1804	210 (LB)	4WD High Indicator Circuit Open or Short to Ground	On-Demand, Continuous
P1806	210 (LB)	4WD High Indicator Short to Battery	On-Demand, Continuous
P1824	779 (BR)	4WD Electric Clutch Relay Circuit Open or Short to Ground	On-Demand, Continuous
P1826	779 (BR)	4WD Electric Clutch Relay Short to Battery	Continuous
P1832	605 (R)	Transfer Case 4WD Solenoid Circuit Open or Short to Ground	Continuous
P1834	605 (R)	Transfer Case 4WD Solenoid Short to Battery	On-Demand, Continuous
P1876	145 (GY/BK)	Transfer Case 2WD Solenoid Circuit Open or Short to Ground	On-Demand, Continuous
P1877	145 (GY/BK)	Transfer Case 2WD Solenoid Short to Battery	On-Demand, Continuous







PID	Circuit	Circuit Description	Expected Values
4WDELCL	779 (BR)	4WD Electric Clutch Relay Coil Status	ON---, OFF---, ON-B-, OFF O-G
4WDHIGH	777 (Y)	4WD High Indicator Status	ON---, OFF---, ON-B-, OFF O-G
2WDSOL	145 (GY/BK)	2WD Solenoid Status	ON---, OFF---, ON-B-, OFF O-G
4WDSOL	605 (R)	4WD Solenoid Status	ON---, OFF---, ON-B-, OFF O-G
IGN_GEM	297 (BK/LG)	Ignition Switch Status	START, RUN, OFF, ACC



TEST CONDITIONS	TEST DETAILS/RESULTS/ACTIONS
<p>F1 CHECK THE VOLTAGE OUTPUT FROM FUSE 15 (5A)</p>  <p style="text-align: right;">K26161-A</p>	<p>2 Measure the voltage between fuse 15 (5A) pin 1, and ground.</p> <ul style="list-style-type: none">• Is the voltage greater than 10 volts? <p>→ Yes GO to F4.</p> <p>→ No GO to F2.</p>
<p>F2 CHECK FUSES 15 (5A) and 22 (50A)</p>	<p>1 Check fuse 15 (5A) in the fuse junction panel and fuse 22 (50A) in the power distribution box.</p> <ul style="list-style-type: none">• Are the fuses OK? <p>→ Yes GO to F3.</p> <p>→ No REPLACE the fuse(s). CLEAR the DTCs. TEST the system for normal operation. If the fuse(s) fails again, CHECK for a short to ground. REPAIR as necessary.</p>





TEST CONDITIONS	TEST DETAILS/RESULTS/ACTIONS
<p>F3 CHECK CIRCUIT 1052 (T/BK) FOR VOLTAGE</p>  <p>Fuse Junction Panel C243</p> <p>K28158-A</p>	<p>2 Measure the voltage between fuse junction panel C243-11, circuit 1052 (T/BK), and ground.</p> <ul style="list-style-type: none"> • Is the voltage greater than 10 volts? <p>→ Yes REPLACE the fuse junction panel. CLEAR the DTCs. TEST the system for normal operation.</p> <p>→ No REPAIR circuit 1052 (T/BK). CLEAR the DTCs. TEST the system for normal operation.</p>
<p>F4 CHECK THE IGNITION STATES</p>  <p>New Generation STAR (NGS) Tester</p>	<p>3 NOTE: If the vehicle is equipped with a manual transmission, depress the clutch pedal while turning the ignition switch to the START.</p> <p>Monitor the PID IGN_GEM and rotate the ignition switch through the START, RUN, OFF, and ACC positions.</p> <ul style="list-style-type: none"> • Do the PID values agree with the ignition switch positions? <p>→ Yes GO to F5.</p> <p>→ No REPAIR the ignition circuit(s) (RUN/ACC: circuit 297 [BK/LG], RUN: circuit 1040 [R/LB], START: circuit 32 [R/LB] or circuit 481 [GY/Y]) in question. CLEAR the DTCs. TEST the system for normal operation.</p>



TEST CONDITIONS	TEST DETAILS/RESULTS/ACTIONS
F5 RETRIEVE THE DIAGNOSTIC TROUBLE CODES (DTCs)	
 <p>Retrieve and Document Continuous DTCs</p>  <p>Clear Continuous DTCs</p>  <p>On-Demand Self-Test</p>	<ul style="list-style-type: none">• Are any DTCs recorded? <p>→ Yes If DTC B1342, REPLACE the GEM. CLEAR the DTCs. TEST the system for normal operation.</p> <p>If DTC P1824, GO to F11.</p> <p>If DTC P1826, GO to F11.</p> <p>If DTC P1804, GO to Pinpoint Test H.</p> <p>If DTC P1806, GO to Pinpoint Test H.</p> <p>If DTC P1832, GO to Pinpoint Test G.</p> <p>If DTC P1834, GO to Pinpoint Test G.</p> <p>If DTC P1876, GO to Pinpoint Test G.</p> <p>If DTC P1877, GO to Pinpoint Test G.</p> <p>→ No GO to F6.</p>



TEST CONDITIONS	TEST DETAILS/RESULTS/ACTIONS
<p data-bbox="207 111 625 138">F6 CHECK THE 4x4 INDICATORS</p> <p data-bbox="483 174 508 205">1</p>  <p data-bbox="483 373 508 405">2</p>  <p data-bbox="672 730 764 751">C11964-B</p> <p data-bbox="483 800 508 831">3</p>  <p data-bbox="672 1157 764 1178">C11965-B</p>	<p data-bbox="813 373 1312 405">2 Shift into 2H. Both indicators should be off.</p> <p data-bbox="813 800 1386 831">3 Shift into 4H. The 4x4 indicator should illuminate.</p>



TEST CONDITIONS	TEST DETAILS/RESULTS/ACTIONS
<p>F6 CHECK THE 4x4 INDICATORS</p> <p style="text-align: center;">4</p>  <p style="text-align: right;">C11986-B</p>	<p>4 Shift into 4L. The low range indicator should illuminate; the 4x4 indicator should remain illuminated.</p> <ul style="list-style-type: none"> • Do the indicators operate correctly? <p>→ Yes GO to F7.</p> <p>→ No If the 4H indicator does not operate, GO to E7.</p> <p>If the 4L indicator does not operate, GO to Pinpoint Test H.</p>
<p>F7 CHECK 4x4 LAMP PROVEOUT</p> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p>1</p>  </div> <div style="text-align: center;"> <p>2</p>  </div> </div>	<ul style="list-style-type: none"> • Does the 4x4 lamp proveout (illuminate) for two seconds after starting the vehicle? <p>→ Yes GO to F25.</p> <p>→ No GO to Pinpoint Test H.</p>
<p>F8 CHECK THE FRONT AXLE ENGAGEMENT</p> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p>1</p>  </div> <div style="text-align: center;"> <p>2</p>  </div> </div> <div style="text-align: center; margin-top: 20px;"> <p>4</p>  </div>	<p>2 Set the active commands AXLE ENGG to ON and AXLE DSCN to OFF and drive a short distance.</p> <p>3 Raise and support the vehicle with the engine running.</p>






TEST CONDITIONS	TEST DETAILS/RESULTS/ACTIONS
F8 CHECK THE FRONT AXLE ENGAGEMENT	<p>5 Spin one front tire. The other front tire should spin in the opposite direction.</p> <ul style="list-style-type: none"> • Is the axle disconnect working properly? <p>→ Yes Exit active command mode and GO to F9.</p> <p>→ No GO to Pinpoint Test G.</p>
<p>F9 CHECK THE FRONT DRIVESHAFT ENGAGEMENT</p> <p style="text-align: center;">1</p>  <p style="text-align: center;">C11985-B</p> <p style="text-align: center;">2</p> 	<p>1 Shift into 4H.</p> <p>3 The front and rear driveshaft should both spin.</p> <ul style="list-style-type: none"> • Is the transfer case locking the front driveshaft to the rear driveshaft? <p>→ Yes GO to F10.</p> <p>→ No Mechanical transfer case concern.</p>



TEST CONDITIONS	TEST DETAILS/RESULTS/ACTIONS
<p>F10 CHECK THE FRONT DRIVESHAFT DISENGAGEMENT</p> <p>1</p>  <p>C11984-B</p> <p>2</p> 	<p>1 NOTE: When 2H is engaged, the front driveshaft may spin due to viscous drag in the transfer case, especially if cold. If this occurs, the front driveline can be easily stopped.</p> <p>Shift into 2H. Only the rear driveshaft should spin.</p> <p>• Does only the rear driveshaft spin?</p> <p>→ Yes GO to F11.</p> <p>→ No</p>
<p>F11 CHECK THE FRONT AXLE DISENGAGEMENT</p> <p>1</p>  <p>2</p> 	<p>1 Set the active commands AXLE ENGG to OFF and AXLE DSCN to ON.</p>



TEST CONDITIONS	TEST DETAILS/RESULTS/ACTIONS
F11 CHECK THE FRONT AXLE DISENGAGEMENT	<p>3 Spin one front tire. The other front tire should not spin.</p> <ul style="list-style-type: none"> • Is the axle disconnect working properly? <p>→ Yes GO to F12.</p> <p>→ No GO to Pinpoint Test G.</p>
F12 CHECK THE MECHANICAL SHIFT ON THE FLY (MSOF) CLUTCH RELAY COIL CIRCUIT ACTIVATION 	<p>2 Set the active command SHIFT CLUTCH to ENERGIZED.</p> <p>3 Monitor the PID 4WDELCL.</p> <ul style="list-style-type: none"> • Is the PID 4WDELCL indicating ON---? <p>→ Yes GO to F13.</p> <p>→ No If the PID 4WDELCL displays ON-B-, GO to F18.</p>
F13 CHECK THE MSOF CLUTCH RELAY COIL CIRCUIT DE-ACTIVATION 	<p>1 Set the active command SHIFT CLUTCH to DE-ENERGIZED.</p> <p>2 Monitor the PID 4WDELCL.</p> <ul style="list-style-type: none"> • Is the PID 4WDELCL indicating OFF---? <p>→ Yes GO to F20.</p> <p>→ No If the PID 4WDELCL displays OFF O-G, GO to F14.</p>





TEST CONDITIONS	TEST DETAILS/RESULTS/ACTIONS
F14 CHECK THE VOLTAGE TO THE MSOF CLUTCH RELAY COIL CIRCUIT	
 <p style="text-align: center;">MSOF Clutch Relay</p> <p style="text-align: right;">K25619-A</p>	<p>4 Measure the voltage between MSOF clutch relay connector pin 1, circuit 294 (W/LB), and ground.</p> <ul style="list-style-type: none"> • Is the voltage greater than 10 volts? <p>→ Yes GO to F15.</p> <p>→ No REPAIR circuit 294 (W/LB). CLEAR the DTCs. TEST the system for normal operation.</p>
F15 CHECK THE MSOF CLUTCH RELAY	
	<p>2 Check the MSOF clutch relay; refer to the Relay Component Test</p> <ul style="list-style-type: none"> • Is the MSOF clutch relay OK? <p>→ Yes GO to F16.</p> <p>→ No REPLACE the MSOF clutch relay. CLEAR the DTCs. TEST the system for normal operation.</p>





TEST CONDITIONS	TEST DETAILS/RESULTS/ACTIONS
<p>F16 CHECK CIRCUIT 976 (O) FOR SHORT TO GROUND</p>  <p style="text-align: center;">K25651-A</p>	<p>2 Measure the resistance between MSOF clutch relay connector pin 2, circuit 976 (O), and ground.</p> <ul style="list-style-type: none"> • Is the resistance greater than 10,000 ohms? <p>→ Yes GO to F17.</p> <p>→ No REPAIR circuit 976 (O). CLEAR the DTCs. TEST the system for normal operation.</p>
<p>F17 CHECK CIRCUIT 976 (O) FOR OPEN</p>  <p style="text-align: center;">C13152-A</p>	<p>1 Measure the resistance between MSOF clutch relay connector pin 2, circuit 976 (O), and GEM C241-14, circuit 976 (O).</p> <ul style="list-style-type: none"> • Is the resistance less than 5 ohms? <p>→ Yes REPLACE the GEM. CLEAR the DTCs. TEST the system for normal operation.</p> <p>→ No REPAIR circuit 976 (O). CLEAR the DTCs. TEST the system for normal operation.</p>



TEST CONDITIONS	TEST DETAILS/RESULTS/ACTIONS
<p>F18 CHECK THE MSOF CLUTCH RELAY</p>   <p>MSOF Clutch Relay</p>	<p>3 Check the MSOF clutch relay; refer to the Relay Component Test</p> <ul style="list-style-type: none"> • Is the MSOF clutch relay OK? <p>→ Yes GO to F19.</p> <p>→ No REPLACE the MSOF clutch relay. CLEAR the DTCs. TEST the system for normal operation.</p>
<p>F19 CHECK CIRCUIT 976 (O) FOR SHORT TO POWER</p>   <p>GEM C241</p>  <p>C13153-A</p>	<p>3 Measure the voltage between GEM C241-14, circuit 976 (O), and ground.</p> <ul style="list-style-type: none"> • Is any voltage indicated? <p>→ Yes REPAIR circuit 976 (O). CLEAR the DTCs. TEST the system for normal operation.</p> <p>→ No REPLACE the GEM. CLEAR the DTCs. TEST the system for normal operation.</p>



TEST CONDITIONS	TEST DETAILS/RESULTS/ACTIONS
<p>F20 CHECK CIRCUIT 779 (BR) FOR VOLTAGE — SHIFT CLUTCH ENERGIZED</p>  <p>MSOF Clutch C260</p> <p>C11987-A</p>	<p>4 Set the active command SHIFT CLUTCH to ENERGIZED.</p> <p>5 Measure the voltage between MSOF clutch C260-1, circuit 779 (BR), and ground.</p> <ul style="list-style-type: none"> • Is the voltage greater than 10 volts? <p>→ Yes GO to F21.</p> <p>→ No GO to F23.</p>
<p>F21 CHECK CIRCUIT 779 (BR) FOR VOLTAGE — SHIFT CLUTCH DE-ENERGIZED</p>  <p>MSOF Clutch C260</p> <p>C11987-A</p>	<p>4 Set the active command SHIFT CLUTCH to DE-ENERGIZED.</p> <p>5 Measure the voltage between MSOF clutch C260-1, circuit 779 (BR), and ground.</p> <ul style="list-style-type: none"> • Is the voltage 0 volts? <p>→ Yes GO to F29.</p> <p>→ No GO to F22.</p>




TEST CONDITIONS	TEST DETAILS/RESULTS/ACTIONS
<p>F22 CHECK CIRCUIT 779 (BR) FOR SHORT TO POWER</p>  <p>MSOF Clutch Relay</p> <p>C13155-A</p>	<p>4 Measure the voltage between MSOF clutch C260-1, circuit 779 (BR), and ground.</p> <ul style="list-style-type: none"> • Is the voltage greater than 10 volts? <p>→ Yes REPAIR circuit 779 (BR). CLEAR the DTCs. TEST the system for normal operation.</p> <p>→ No REPLACE the MSOF clutch relay. CLEAR the DTCs. TEST the system for normal operation.</p>
<p>F23 CHECK THE VOLTAGE TO THE MSOF CLUTCH RELAY SWITCH</p>  <p>MSOF Clutch Relay</p> <p>K25821-A</p>	<p>3 Measure the voltage between MSOF clutch relay connector pin 3, circuit 704 (DG/LG) and ground.</p> <ul style="list-style-type: none"> • Is the voltage greater than 10 volts? <p>→ Yes GO to F24.</p> <p>→ No CHECK fuse 17 (30A). REPLACE if necessary. If fuse 17 (30A) is OK, REPAIR circuit 704 (DG/LG). CLEAR the DTCs. TEST the system for normal operation.</p>



TEST CONDITIONS	TEST DETAILS/RESULTS/ACTIONS
<p>F24 CHECK CIRCUIT 779 (BR) FOR OPEN</p> <p>1</p>  <p>C13164-A</p>	<p>1 Measure the resistance between MSOF clutch relay connector pin 5, circuit 779 (BR), and MSOF clutch C260-1, circuit 779 (BR).</p> <ul style="list-style-type: none"> • Is the resistance less than 5 ohms? <p>→ Yes REPLACE the MSOF clutch relay. CLEAR the DTCs. TEST the system for normal operation.</p> <p>→ No REPAIR circuit 779 (BR). CLEAR the DTCs. TEST the system for normal operation.</p>
<p>F25 CHECK CIRCUIT 783 (GY) FOR SHORT TO GROUND</p> <p>1</p>  <p>2</p>  <p>GEM C241</p> <p>3</p>  <p>C11964-B</p>	<p>3 Shift in 2H.</p>





TEST CONDITIONS	TEST DETAILS/RESULTS/ACTIONS
<p>F25 CHECK CIRCUIT 783 (GY) FOR SHORT TO GROUND</p> <p>4</p>  <p>GC1189-A</p>	<p>4</p> <p>Measure the resistance between GEM C241-3, circuit 783 (GY), and ground.</p> <ul style="list-style-type: none"> • Is the resistance greater than 10,000 ohms? <p>→ Yes GO to F27.</p> <p>→ No GO to F26.</p>
<p>F26 CHECK MSOF HI/LO INDICATOR SWITCH FOR SHORT TO GROUND</p> <p>1</p>  <p>2</p>  <p>MSOF HI/LO Indicator Switch C189</p> <p>3</p>  <p>GC1189-A</p>	<p>3</p> <p>Measure the resistance between GEM C241-3, circuit 783 (GY), and ground.</p> <ul style="list-style-type: none"> • Is the resistance greater than 10,000 ohms? <p>→ Yes REPLACE the MOSF HI/LO indicator switch. CLEAR the DTCs. TEST the system for normal operation.</p> <p>→ No REPAIR circuit 783 (GY). CLEAR the DTCs. TEST the system for normal operation.</p>


TEST CONDITIONS	TEST DETAILS/RESULTS/ACTIONS
F27 CHECK CIRCUIT 783 (GY) BETWEEN GEM C241-3 AND GROUND FOR OPEN	
<p data-bbox="493 170 516 199">1</p>  <p data-bbox="683 531 769 552">C11965-B</p> <p data-bbox="493 600 516 630">2</p>  <p data-bbox="683 961 769 982">GC1189-A</p>	<p data-bbox="818 170 1003 199">1 Shift into 4H</p> <p data-bbox="818 600 1349 657">2 Measure the resistance between GEM C241-3, circuit 783 (GY), and ground.</p> <ul data-bbox="873 684 1256 711" style="list-style-type: none">• Is the resistance less than 5 ohms? <p data-bbox="873 739 1305 795">→ Yes GEM operates properly. System OK.</p> <p data-bbox="873 823 1040 879">→ No GO to F28.</p>




TEST CONDITIONS	TEST DETAILS/RESULTS/ACTIONS
<p>F28 CHECK CIRCUIT 783 (GY) FOR OPEN</p>  <p>MSOF HI/LO Indicator Switch C189</p> <p>GC1190-A</p>	<p>3 Measure the resistance between GEM C241-3, circuit 783 (GY), and MSOF HI/LO indicator switch C189, circuit 783 (GY).</p> <ul style="list-style-type: none"> • Is the resistance less than 5 ohms? <p>→ Yes REPLACE the MOSF HI/LO indicator switch. CLEAR the DTCs. TEST the system for normal operation.</p> <p>→ No REPAIR circuit 783 (GY). CLEAR the DTCs. TEST the system for normal operation.</p>
<p>F29 CHECK THE SYNCHRONIZATION OF THE FRONT OUTPUT</p>  <p>C11964-B</p>	<p>1 Raise and support the vehicle.</p> <p>2 Remove the front driveshaft.</p> <p>3 Shift into 2H.</p>





TEST CONDITIONS	TEST DETAILS/RESULTS/ACTIONS
F29 CHECK THE SYNCHRONIZATION OF THE FRONT OUTPUT	
<p data-bbox="342 155 363 184">4</p>  <p data-bbox="630 155 651 184">5</p>  <p data-bbox="488 453 509 483">7</p>  <p data-bbox="672 810 760 831">C11965-B</p>	<p data-bbox="813 359 834 388">6</p> Increase tire rotation between 20-25 mph (35-40 kph) and hold. <p data-bbox="813 457 834 487">7</p> Shift into 4H. <ul data-bbox="862 512 1317 695" style="list-style-type: none">• Does the front output rotate?→ Yes VERIFY the concern. RETURN to the Symptom Chart.→ No




TEST CONDITIONS	TEST DETAILS/RESULTS/ACTIONS
<p data-bbox="211 115 868 136">G1 CHECK THE POWER OUTPUT FROM FUSE 15 (5A)</p> <div data-bbox="438 168 552 325"><p data-bbox="479 178 511 210">1</p></div> <div data-bbox="479 367 511 399"><p data-bbox="479 367 511 399">2</p></div> <div data-bbox="324 514 665 672"></div> <p data-bbox="673 724 763 745">K26161-A</p>	<p data-bbox="803 367 1364 430">2 Measure the voltage between fuse 15 (5A) pin 1, and ground.</p> <ul data-bbox="860 451 1266 493" style="list-style-type: none">• Is the voltage greater than 10 volts? <p data-bbox="860 504 1023 567">→ Yes GO to G4.</p> <p data-bbox="860 577 1023 640">→ No GO to G2.</p>
<p data-bbox="211 777 682 798">G2 CHECK FUSES 15 (5A) and 22 (50A)</p>	<p data-bbox="803 829 1380 892">1 Check fuse 15 (5A) in the fuse junction panel and fuse 22 (50A) in the power distribution box.</p> <ul data-bbox="860 913 1088 955" style="list-style-type: none">• Are the fuses OK? <p data-bbox="860 966 1023 1029">→ Yes GO to G3.</p> <p data-bbox="860 1039 1396 1186">→ No REPLACE fuse(s). CLEAR the DTCs. TEST the system for normal operation. If the fuse(s) fail again, CHECK for a short to ground. REPAIR as necessary.</p>



TEST CONDITIONS	TEST DETAILS/RESULTS/ACTIONS
<p>G3 CHECK CIRCUIT 1052 (T/BK) FOR VOLTAGE</p>  <p>Fuse Junction Panel C243</p>  <p>K26156-A</p>	<p>2 Measure the voltage between fuse junction panel C243-11, circuit 1052 (T/BK), and chassis ground.</p> <ul style="list-style-type: none"> • Is the voltage greater than 10 volts? <p>→ Yes REPLACE the fuse junction panel. CLEAR the DTCs. TEST the system for normal operation.</p> <p>→ No REPAIR circuit 1052 (T/BK). CLEAR the DTCs. TEST the system for normal operation.</p>
<p>G4 CHECK THE IGNITION STATES</p>  <p>New Generation STAR (NGS) Tester</p> 	<p>2 NOTE: If the vehicle is equipped with a manual transmission, depress the clutch pedal while turning the ignition switch to the START.</p> <p>Monitor the PID IGN__GEM while cycling the ignition switch through the START, RUN, OFF, and ACC positions.</p> <ul style="list-style-type: none"> • Do the PID values agree with the ignition switch positions? <p>→ Yes GO to G5.</p> <p>→ No REPAIR the ignition circuit(s) (RUN/ACC: circuit 297 [BK/LG], RUN: circuit 1040 [R/LB], START: circuit 32 [R/LB] or circuit 481 [GY/Y]) in question. CLEAR the DTCs. TEST the system for normal operation.</p>









TEST CONDITIONS	TEST DETAILS/RESULTS/ACTIONS
G5 RETRIEVE THE DIAGNOSTIC TROUBLE CODES (DTCs)	
 <p>1 Retrieve and Document Continuous DTCs</p> <p>2 Clear Continuous DTCs</p> <p>3 On-Demand Self-Test</p>	<ul style="list-style-type: none">• Are any DTCs recorded? <p>→ Yes If DTC B1342, REPLACE the GEM. CLEAR the DTCs. TEST the system for normal operation.</p> <p>If DTC P1824, GO to Pinpoint Test F.</p> <p>If DTC P1826, GO to Pinpoint Test F.</p> <p>If DTC P1804, GO to Pinpoint Test H.</p> <p>If DTC P1806, GO to Pinpoint Test H.</p> <p>If DTC P1832, GO to G11.</p> <p>If DTC P1834, GO to G11.</p> <p>If DTC P1876, GO to G11.</p> <p>If DTC P1877, GO to G11.</p> <p>→ No GO to G6.</p>








TEST CONDITIONS	TEST DETAILS/RESULTS/ACTIONS
<p>G6 CHECK THE 4x4 INDICATORS</p>	
<p>1</p> 	
<p>2</p>  <p>C11964-B</p>	<p>2 Shift into 2H. Both indicators should be off.</p>
<p>3</p>  <p>C11965-B</p>	<p>3 Shift into 4H. The 4x4 indicator should illuminate.</p>



TEST CONDITIONS	TEST DETAILS/RESULTS/ACTIONS
<p>G6 CHECK THE 4x4 INDICATORS</p> <p style="text-align: center;">4</p>  <p style="text-align: right;">C11986-B</p>	<p>4 Shift into 4L. Low range indicator should illuminate; the 4x4 indicator should remain illuminated.</p> <ul style="list-style-type: none"> • Do the indicators operate correctly? <p>→ Yes GO to G7.</p> <p>→ No If the LOW RANGE indicator does not operate, GO to Pinpoint Test H.</p> <p>If the 4x4 indicator does not operate, VERIFY the 4x4 lamp does not proveout after starting the vehicle, GO to Pinpoint Test H.</p> <p>If 4x4 indicator does proveout, GO to F25.</p>
<p>G7 CHECK THE FRONT AXLE ENGAGEMENT</p> <p>1 </p> <p>2 </p> <p>4 </p>	<p>2 Set the active commands AXLE ENGG to ON and AXLE DSCN to OFF and drive a short distance.</p> <p>3 Raise and support the vehicle with the engine running.</p> <p>5 Spin one front tire. The other front tire should spin in the opposite direction.</p> <ul style="list-style-type: none"> • Is the axle disconnect working properly? <p>→ Yes Exit the active command mode, GO to G8.</p> <p>→ No GO to G11.</p>



TEST CONDITIONS	TEST DETAILS/RESULTS/ACTIONS
G8 CHECK THE FRONT DRIVESHAFT ENGAGEMENT	
<p data-bbox="488 170 516 205">1</p>  <p data-bbox="675 531 764 552">C11985-B</p> <p data-bbox="488 600 516 636">2</p> 	<p data-bbox="813 176 1003 205">1 Shift into 4H.</p> <p data-bbox="813 800 1344 829">3 The front and rear driveshaft should both spin.</p> <ul data-bbox="862 856 1393 909" style="list-style-type: none"> • Is the transfer case locking the front driveshaft to the rear driveshaft? <p data-bbox="862 936 1024 989">→ Yes GO to G9.</p> <p data-bbox="862 1016 1268 1068">→ No Mechanical transfer case concern.</p>
G9 CHECK THE FRONT DRIVESHAFT DISENGAGEMENT	
<p data-bbox="488 1167 516 1203">1</p>  <p data-bbox="675 1528 764 1549">C11984-B</p>	<p data-bbox="813 1167 1393 1283">1 NOTE: When 4WD is disengaged, the front driveshaft may spin due to viscous drag in the transfer case, especially if cold. If this occurs, the front driveline can be easily stopped.</p> <p data-bbox="857 1289 1393 1318">Shift into 2H. Only the rear driveshaft should spin.</p> <ul data-bbox="862 1346 1263 1375" style="list-style-type: none"> • Does only the rear driveshaft spin? <p data-bbox="862 1402 1036 1455">→ Yes GO to G10.</p> <p data-bbox="862 1482 1268 1535">→ No Mechanical transfer case concern.</p>



TEST CONDITIONS	TEST DETAILS/RESULTS/ACTIONS
G10 CHECK THE FRONT AXLE AND THE FRONT DRIVESHAFT ENGAGEMENT	
	<p>1 Set the active commands AXLE ENGG to OFF and AXLE DSCN to ON.</p> <p>3 Spin one front tire. The other front tire should not spin.</p> <ul style="list-style-type: none"> • Is the axle disconnect working properly? <p>→ Yes GO to Pinpoint Test A</p> <p>→ No GO to G11.</p>
G11 CHECK 4WD AND 2WD VACUUM SOLENOID CIRCUITS	
	<p>2 Monitor the PIDs 4WDSOL and 2WDSOL.</p> <p>3 Toggle the active commands AXLE ENGG to ON and AXLE DSCN to ON.</p> <ul style="list-style-type: none"> • Does 4WDSOL indicate ON--- and 2WDSOL indicate ON---? <p>→ Yes GO to G12.</p> <p>→ No If the PID displays ON-B-, GO to G13.</p>




TEST CONDITIONS	TEST DETAILS/RESULTS/ACTIONS
<p>G12 CHECK 4WD AND 2WD VACUUM SOLENOIDS</p>  	<p>1 Monitor the PIDs 4WDSOL and 2WDSOL.</p> <p>2 Toggle the active commands AXLE ENGG to OFF and AXLE DSCN to OFF.</p> <ul style="list-style-type: none"> • Does 4WDSOL indicate OFF--- and 2WDSOL indicate OFF---? <p>→ Yes GO to G22.</p> <p>→ No If PID displays OFF O-G, GO to G15.</p>
<p>G13 CHECK CIRCUITS 145 (GY/BK) AND 605 (R) FOR SHORT(S) TO POWER</p>     <p>4WD Vacuum Solenoid C180 2WD Vacuum Solenoid C181 GEM C241</p>   <p>C13201-A</p>	<p>6 Measure the voltage between 4WD vacuum solenoid C180, circuit 605 (R), 2WD vacuum solenoid C181, circuit 145 (GY/BK), and ground.</p> <ul style="list-style-type: none"> • Is the voltage greater than 10 volts? <p>→ Yes REPAIR the circuit(s) (145 [GY/BK], 605 [R]) in question. CLEAR the DTCs. TEST the system for normal operation.</p> <p>→ No RECONNECT GEM C241, 4WD vacuum solenoid and 2WD vacuum solenoid. GO to G14.</p>

TEST CONDITIONS	TEST DETAILS/RESULTS/ACTIONS
<p>G14 CHECK THE 4WD AND 2WD VACUUM SOLENOIDS</p>  	<p>1 Monitor the PIDS 4WDSOL and 2WDSOL.</p> <p>2 Set the active commands AXLE ENGG and AXLE DSCN to ON.</p> <ul style="list-style-type: none"> • Do the PIDS 4WDSOL and 2WDSOL indicate ON-B-? <p>→ Yes REPLACE the GEM. CLEAR the DTCs. TEST the system for normal operation.</p> <p>→ No REPLACE the vacuum solenoid in question. CLEAR the DTCs. TEST the system for normal operation.</p>
<p>G15 CHECK VOLTAGE TO THE 4WD AND 2WD VACUUM SOLENOIDS</p>     <p>4WD Vacuum Solenoid C180 2WD Vacuum Solenoid C181</p> <p>5</p>  <p>C11954-A</p>	<p>5 Measure the voltage between 4WD vacuum solenoid C180, circuit 294 (W/LB), 2WD vacuum solenoid C181, circuit 294 (W/LB), and ground.</p> <ul style="list-style-type: none"> • Are the voltages greater than 10 volts? <p>→ Yes GO to G16.</p> <p>→ No REPAIR circuit(s) 294 (W/LB) or fuse 23 (10A). CLEAR the DTCs. TEST the system for normal operation.</p>




TEST CONDITIONS	TEST DETAILS/RESULTS/ACTIONS
<p>G16 CHECK THE 4WD VACUUM SOLENOID</p>  <p>C11955-A</p>	<p>2 Measure the resistance between terminals 1 and 2 on the 4WD vacuum solenoid.</p> <ul style="list-style-type: none">• Is the resistance between 50 and 100 ohms? <p>→ Yes GO to G17.</p> <p>→ No REPLACE the 4WD vacuum solenoid. CLEAR the DTCs. TEST the system for normal operation.</p>
<p>G17 CHECK THE 2WD VACUUM SOLENOID</p>  <p>C11956-A</p>	<p>1 Measure the resistance between terminals 1 and 2 on the 2WD vacuum solenoid.</p> <ul style="list-style-type: none">• Is the resistance between 50 and 100 ohms? <p>→ Yes GO to G18.</p> <p>→ No REPLACE the 2WD vacuum solenoid. CLEAR the DTCs. TEST the system for normal operation.</p>



TEST CONDITIONS	TEST DETAILS/RESULTS/ACTIONS
<p>G18 CHECK CIRCUIT 145 (GY/BK) FOR OPEN</p>  <p>GEM C241</p> <p>C13202-A</p>	<p>2 Measure the resistance between GEM C241-2, circuit 145 (GY/BK), and 2WD vacuum solenoid C181, circuit 145 (GY/BK).</p> <ul style="list-style-type: none"> • Is the resistance less than 5 ohms? <p>→ Yes GO to G19.</p> <p>→ No REPAIR circuit 145 (GY/BK). CLEAR the DTCs. TEST the system for normal operation.</p>
<p>G19 CHECK CIRCUIT 605 (R) FOR OPEN</p>  <p>GC0688-A</p>	<p>1 Measure the resistance between GEM C241-7, circuit 605 (R), and 4WD vacuum solenoid C180, circuit 605 (R).</p> <ul style="list-style-type: none"> • Is the resistance less than 5 ohms? <p>→ Yes GO to G20.</p> <p>→ No REPAIR circuit 605 (R). CLEAR the DTCs. TEST the system for normal operation.</p>



TEST CONDITIONS	TEST DETAILS/RESULTS/ACTIONS
<p>G20 CHECK CIRCUIT 145 (GY/BK) FOR SHORT TO GROUND</p> <p>1</p>  <p>C13204-A</p>	<p>1</p> <p>Measure the resistance between GEM C241-2, circuit 145 (GY/BK), and ground.</p> <ul style="list-style-type: none">• Is the resistance greater than 10,000 ohms? <p>→ Yes GO to G21.</p> <p>→ No REPAIR circuit 145 (GY/BK). CLEAR the DTCs. TEST the system for normal operation.</p>
<p>G21 CHECK CIRCUIT 605 (R) FOR SHORT TO GROUND</p> <p>1</p>  <p>C13205-A</p>	<p>1</p> <p>Measure the resistance between GEM C241-7, circuit 605 (R), and ground.</p> <ul style="list-style-type: none">• Is the resistance greater than 10,000 ohms? <p>→ Yes REPLACE the GEM. CLEAR the DTCs. TEST the system for normal operation.</p> <p>→ No REPAIR circuit 605 (R). CLEAR the DTCs. TEST the system for normal operation.</p>




TEST CONDITIONS	TEST DETAILS/RESULTS/ACTIONS
<p data-bbox="203 113 1096 142">G22 CHECK THE VACUUM AT THE 4WD AND 2WD VACUUM SOLENOIDS</p>  <p data-bbox="477 176 496 205">1</p>	<p data-bbox="803 373 1372 457">2 Verify the vacuum (with the engine running) at the feed lines on the 2WD and 4WD vacuum solenoids.</p> <ul data-bbox="857 478 1096 508" style="list-style-type: none">• Is vacuum present? <p data-bbox="857 533 1031 583">→ Yes GO to G23.</p> <p data-bbox="857 613 1339 718">→ No REPAIR the vacuum feed line in question. CLEAR the DTCs. TEST the system for normal operation.</p>
<p data-bbox="203 730 1177 760">G23 CHECK THE 4WD AND 2WD VACUUM SOLENOIDS BY APPLYING VACUUM</p>  <p data-bbox="477 991 496 1020">2</p> <p data-bbox="672 1348 760 1369">C13206-A</p>  <p data-bbox="483 1423 503 1453">3</p>	<p data-bbox="803 991 1323 1054">2 Connect Vacuum Pump to the feed line of the vacuum solenoid being tested.</p>





TEST CONDITIONS	TEST DETAILS/RESULTS/ACTIONS
G23 CHECK THE 4WD AND 2WD VACUUM SOLENOIDS BY APPLYING VACUUM	
	<p data-bbox="812 157 1315 189">4 Monitor the PIDs 2WDSOL and 4WDSOL.</p> <p data-bbox="812 231 1347 283">5 Toggle the active command AXLE ENGG and AXLE DSCN to OFF.</p> <p data-bbox="812 325 1396 378">6 Apply vacuum and verify the vacuum solenoids are closed.</p> <ul data-bbox="860 409 1169 441" style="list-style-type: none">• Are the solenoids closed? <p data-bbox="860 462 1380 514">→ Yes RELEASE the applied vacuum. GO to G24.</p> <p data-bbox="860 535 1380 640">→ No REPLACE the vacuum solenoid in question. CLEAR the DTCs. TEST the system for normal operation.</p>
G24 CHECK THE 4WD AND 2WD VACUUM SOLENOIDS — ON	
	<p data-bbox="812 724 1347 777">1 Toggle the active command AXLE ENGG and AXLE DSCN to ON.</p> <p data-bbox="812 819 1396 871">2 Apply vacuum and verify the vacuum solenoids are open.</p> <ul data-bbox="860 903 1169 934" style="list-style-type: none">• Are the solenoids OPEN? <p data-bbox="860 955 1380 1008">→ Yes RELEASE the applied vacuum. GO to G25.</p> <p data-bbox="860 1029 1380 1134">→ No REPLACE the vacuum solenoid in question. CLEAR the DTCs. TEST the system for normal operation.</p>




TEST CONDITIONS	TEST DETAILS/RESULTS/ACTIONS
<p data-bbox="207 117 1015 142">G25 CHECK THE VACUUM FEED LINES TO THE VACUUM MOTOR</p> 	<p data-bbox="803 380 1377 436">2 Verify the feed lines from the vacuum solenoids to the vacuum motor are OK.</p> <ul data-bbox="862 464 1128 489" style="list-style-type: none">• Are the feed lines OK? <p data-bbox="862 516 1386 573">→ Yes RECONNECT the vacuum lines, GO to G26.</p> <p data-bbox="862 600 1386 699">→ No REPAIR the feed line(s) in question. CLEAR the DTCs. TEST the system for normal operation.</p>
<p data-bbox="207 705 657 730">G26 CHECK THE VACUUM MOTOR</p>  	<p data-bbox="803 772 1317 798">1 Remove the linkage from the vacuum motor.</p> <p data-bbox="803 846 1377 903">3 Toggle the active commands AXLE ENGG to ON and AXLE DSCN to OFF.</p> <ul data-bbox="862 930 1365 987" style="list-style-type: none">• Does the vacuum motor move to the engaged position? <p data-bbox="862 1014 1386 1071">→ Yes REPAIR the front axle assembly. CLEAR the DTCs.</p> <p data-bbox="862 1119 1333 1218">→ No REPAIR the vacuum motor. CLEAR the DTCs. TEST the system for normal operation.</p>



TEST CONDITIONS	TEST DETAILS/RESULTS/ACTIONS
<p data-bbox="207 113 889 142">H1 CHECK THE VOLTAGE OUTPUT FROM FUSE 15 (5A)</p> <div data-bbox="440 174 548 327"><p data-bbox="483 174 505 201">1</p></div> <div data-bbox="483 373 505 401">2</div> <div data-bbox="329 520 662 667"><p data-bbox="673 730 760 751">K28161-A</p></div>	<p data-bbox="808 373 1360 436">2 Measure the voltage between fuse 15 (5A) pin 1, and ground.</p> <ul data-bbox="862 457 1263 489" style="list-style-type: none">• Is the voltage greater than 10 volts? <p data-bbox="862 510 1024 562">→ Yes GO to H4.</p> <p data-bbox="862 590 1024 642">→ No GO to H2.</p>
<p data-bbox="207 772 678 802">H2 CHECK FUSES 15 (5A) and 22 (50A)</p>	<p data-bbox="808 835 1377 898">1 Check fuse 15 (5A) in the fuse junction panel and fuse 22 (50A) in the power distribution box.</p> <ul data-bbox="862 919 1089 951" style="list-style-type: none">• Are the fuses OK? <p data-bbox="862 972 1024 1024">→ Yes GO to H3.</p> <p data-bbox="862 1052 1393 1182">→ No REPLACE fuse(s). CLEAR the DTCs. TEST the system for normal operation. If the fuse(s) fail again, CHECK for a short to ground. REPAIR as necessary.</p>




TEST CONDITIONS	TEST DETAILS/RESULTS/ACTIONS
<p>H3 CHECK CIRCUIT 1052 (T/BK) FOR VOLTAGE</p>  <p>Fuse Junction Panel C243</p> <p>K26156-A</p>	<p>2 Measure the voltage between fuse junction panel C243-11, circuit 1052 (T/BK), and ground.</p> <ul style="list-style-type: none"> • Is the voltage greater than 10 volts? <p>→ Yes REPLACE the fuse junction panel. CLEAR the DTCs. TEST the system for normal operation.</p> <p>→ No REPAIR circuit 1052 (T/BK). CLEAR the DTCs. TEST the system for normal operation.</p>
<p>H4 CHECK THE IGNITION STATES</p>  <p>New Generation STAR (NGS) Tester</p>	<p>2 NOTE: If the vehicle is equipped with a manual transmission, depress the clutch pedal while turning the ignition switch to the START.</p> <p>Monitor the PID IGN_GEM while turning the ignition switch through the START, RUN, OFF, and ACC positions.</p> <ul style="list-style-type: none"> • Do the PID values agree with the ignition switch positions? <p>→ Yes GO to H5.</p> <p>→ No REPAIR the ignition circuit(s) (RUN/ACC: circuit 297 [BK/LG], RUN: circuit 1040 [R/LB], START: circuit 32 [R/LB] or circuit 481 [GY/Y]) in question. CLEAR the DTCs. TEST the system for normal operation.</p>




TEST CONDITIONS	TEST DETAILS/RESULTS/ACTIONS
H5 RETRIEVE THE DIAGNOSTIC TROUBLE CODES (DTCs)	
<div style="display: flex; justify-content: space-around; align-items: flex-start;"><div style="text-align: center;"><p>1</p><p>Retrieve and Document Continuous DTCs</p></div><div style="text-align: center;"><p>2</p><p>Clear Continuous DTCs</p></div><div style="text-align: center;"><p>3</p><p>On-Demand Self-Test</p></div></div>	<ul style="list-style-type: none">• Are any DTCs recorded? <p>→ Yes If DTC B1342, REPLACE the GEM. CLEAR the DTCs. TEST the system for normal operation.</p> <p>If DTC P1824, GO to Pinpoint Test E.</p> <p>If DTC P1826, GO to Pinpoint Test E.</p> <p>If DTC P1804, GO to H6.</p> <p>If DTC P1806, GO to H6.</p> <p>If DTC P1832, GO to Pinpoint Test G.</p> <p>If DTC P1834, GO to Pinpoint Test G.</p> <p>If DTC P1876, GO to Pinpoint Test G.</p> <p>If DTC P1877, GO to Pinpoint Test G.</p> <p>→ No GO to H6.</p>




TEST CONDITIONS	TEST DETAILS/RESULTS/ACTIONS
<p>H6 CHECK THE 4x4 INDICATORS</p> <p>1</p>  <p>2</p>  <p>C11964-B</p> <p>3</p>  <p>C11965-B</p> <p>4</p>  <p>C11966-B</p>	<p>2 Shift into 2H. Both indicators should be off.</p> <p>3 Shift into 4H. The 4x4 indicator should illuminate.</p> <p>4 Shift into 4L. Low range indicator should illuminate; the 4x4 indicator should remain illuminated.</p> <ul style="list-style-type: none"> • Do the indicators operate correctly? <p>→ Yes Indicators operating correctly.</p> <p>→ No If the high indicator is inoperative, GO to H7.</p> <p>If the low indicator is inoperative, GO to H17.</p>



TEST CONDITIONS	TEST DETAILS/RESULTS/ACTIONS
<p>H7 CHECK THE GEM 4WD HIGH OUTPUT</p>  	<p>1 Monitor the PID 4WDHIGH.</p> <p>2 Toggle the active command HIGH LAMP to ON and then OFF. The 4x4 indicator should illuminate then go off.</p> <ul style="list-style-type: none"> • Does the PID 4WDHIGH display ON-B-? <p>→ Yes GO to H15.</p> <p>→ No If the PID 4WDHIGH displays OFF O-G and the lamp stays on continuously, GO to H13.</p> <p>If the PID 4WDHIGH displays OFF O-G and the lamp does not illuminate, GO to H8.</p>
<p>H8 CHECK THE 4X4 HIGH INDICATOR BULB</p> 	<p>2 Remove and check the 4x4 HIGH indicator bulb.</p> <ul style="list-style-type: none"> • Is the bulb OK? <p>→ Yes GO to H9.</p> <p>→ No REPLACE the bulb. CLEAR the DTCs. TEST the system for normal operation.</p>





TEST CONDITIONS	TEST DETAILS/RESULTS/ACTIONS
<p>H9 CHECK FOR VOLTAGE AT THE 4x4 LAMP</p> 	<p>2 Measure the voltage between 4x4 HIGH lamp socket and ground.</p> <ul style="list-style-type: none"> • Is the voltage greater than 10 volts? <p>→ Yes GO to H11.</p> <p>→ No GO to H10.</p>
<p>H10 CHECK THE VOLTAGE TO THE INDICATORS</p>  <p>Instrument Cluster C238</p>	<p>4 Measure the voltage between instrument cluster C238-12, circuit 640 (R/Y), and ground.</p> <ul style="list-style-type: none"> • Is the voltage greater than 10 volts? <p>→ Yes REPLACE the instrument cluster. CLEAR the DTCs. TEST the system for normal operation.</p> <p>→ No CHECK fuse 29 (5A). REPLACE if necessary. If OK, REPAIR circuit 640 (R/Y). CLEAR the DTCs. TEST the system for normal operation.</p>



TEST CONDITIONS	TEST DETAILS/RESULTS/ACTIONS
H11 CHECK THE INSTRUMENT CLUSTER FOR OPEN	
<p data-bbox="305 170 412 323">1 </p> <p data-bbox="591 170 698 323">2 </p> <p data-bbox="548 338 740 359">Instrument Cluster C236</p> <p data-bbox="493 401 516 430">3</p>  <p data-bbox="678 1171 769 1192">GC1200-A</p>	<p data-bbox="818 401 1386 457">3 Measure the resistance between 4x4 HIGH socket and instrument cluster terminal 4.</p> <ul data-bbox="867 485 1256 512" style="list-style-type: none">• Is the resistance less than 5 ohms? <p data-bbox="867 541 1045 590">→ Yes GO to H12.</p> <p data-bbox="867 617 1370 722">→ No REPLACE the instrument cluster. CLEAR the DTCs. TEST the system for normal operation.</p>



TEST CONDITIONS	TEST DETAILS/RESULTS/ACTIONS
<p>H12 CHECK CIRCUIT 210 (LB) FOR OPEN</p> <p>1</p>  <p>GEM C241</p> <p>2</p>  <p>C13163-A</p>	<p>2</p> <p>Measure the resistance between GEM C241-9, circuit 210 (LB), and instrument cluster C236-4, circuit 210 (LB).</p> <ul style="list-style-type: none"> • Is the resistance less than 5 ohms? <p>→ Yes REPLACE the GEM. CLEAR the DTCs. TEST the system for normal operation.</p> <p>→ No REPAIR circuit 210 (LB). CLEAR the DTCs. TEST the system for normal operation.</p>
<p>H13 CHECK CIRCUIT 210 (LB) FOR SHORT TO GROUND</p> <p>1</p>  <p>C13209-A</p>	<p>1</p> <p>Measure the resistance between GEM C241-9, circuit 210 (LB), and ground.</p> <ul style="list-style-type: none"> • Is the resistance greater than 10,000 ohms? <p>→ Yes RECONNECT instrument cluster C236. GO to H14.</p> <p>→ No REPAIR circuit 210 (LB). CLEAR the DTCs. TEST the system for normal operation.</p>



TEST CONDITIONS	TEST DETAILS/RESULTS/ACTIONS
<p>H14 CHECK THE INSTRUMENT CLUSTER FOR SHORT TO GROUND</p> 	<ul style="list-style-type: none"> • Is the 4x4 HIGH indicator illuminated? <p>→ Yes REPLACE the instrument cluster. CLEAR the DTCs. TEST the system for normal operation.</p> <p>→ No REPLACE the GEM. CLEAR the DTCs. TEST the system for normal operation.</p>
<p>H15 CHECK CIRCUIT 210 (LB) FOR SHORT TO POWER</p> 	<p>5 Measure the voltage between GEM C241-9, circuit 210 (LB), and ground.</p> <ul style="list-style-type: none"> • Is any voltage indicated? <p>→ Yes REPAIR circuit 210 (LB). CLEAR the DTCs. TEST the system for normal operation.</p> <p>→ No GO to H16.</p>
<p>H16 CHECK THE INSTRUMENT CLUSTER FOR SHORT TO POWER</p> 	<p>1 Set the active command mode HIGH LAMP to ON.</p>

TEST CONDITIONS	TEST DETAILS/RESULTS/ACTIONS
<p>H16 CHECK THE INSTRUMENT CLUSTER FOR SHORT TO POWER</p> 	<p>2 Monitor the PID 4WDHIGH.</p> <ul style="list-style-type: none"> • Does the PID indicate ON-B-? <p>→ Yes REPLACE the GEM. CLEAR the DTCs. TEST the system for normal operation.</p> <p>→ No REPLACE the instrument cluster. CLEAR the DTCs. TEST the system for normal operation.</p>
<p>H17 CHECK THE 4WD INDICATOR SWITCH</p>  <p>4WD Indicator Switch C189</p> <p>C11970-A</p>	<p>3 Measure the resistance between circuit 784 (LB/BK) terminal of the 4WD indicator switch and ground with the 4WD indicator switch in all switch positions.</p> <ul style="list-style-type: none"> • Is the resistance greater than 10,000 ohms with the 4WD indicator switch in the 2H and 4H positions and less than 5 ohms with the 4WD indicator switch in the 4L position? <p>→ Yes GO to H18.</p> <p>→ No REPLACE the 4WD indicator switch. CLEAR the DTCs. TEST the system for normal operation.</p>

TEST CONDITIONS	TEST DETAILS/RESULTS/ACTIONS
H18 CHECK THE VOLTAGE TO THE INSTRUMENT CLUSTER	
<div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p>1</p>  <p>Instrument Cluster C238</p> </div> <div style="text-align: center;"> <p>2</p>  </div> </div> <div style="text-align: center; margin-top: 20px;"> <p>3</p>  </div>	<p>3 Measure the voltage between instrument cluster C238-12, circuit 640 (R/Y), and ground.</p> <ul style="list-style-type: none"> • Is the voltage greater than 10 volts? <p>→ Yes GO to H19.</p> <p>→ No CHECK fuse 29 (5A). REPLACE if necessary. If OK, REPAIR circuit 640 (R/Y). CLEAR the DTCs. TEST the system for normal operation.</p>
H19 CHECK THE 4X4 LOW INDICATOR	
<div style="text-align: center;"> <p>1</p>  </div>	<p>2 Remove and check the 4x4 low indicator bulb.</p> <ul style="list-style-type: none"> • Is the bulb OK? <p>→ Yes REINSTALL the 4x4 low indicator bulb. GO to H20.</p> <p>→ No REPLACE the bulb. CLEAR the DTCs. TEST the system for normal operation.</p>

TEST CONDITIONS	TEST DETAILS/RESULTS/ACTIONS
<p>H20 CHECK CIRCUIT 975 (BR/Y) FOR OPEN</p>  <p>GEM C241 Instrument Cluster C236</p> <p>C13167-A</p>	<p>3 Measure the resistance between GEM C241-10, circuit 975 (BR/Y), and instrument cluster C236-3, circuit 975 (BR/Y).</p> <ul style="list-style-type: none"> • Is the resistance less than 5 ohms? <p>→ Yes RECONNECT instrument cluster C236. GO to H21.</p> <p>→ No REPAIR circuit 975 (BR/Y). CLEAR the DTCs. TEST the system for normal operation.</p>
<p>H21 CHECK THE INSTRUMENT CLUSTER --- 4x4 LOW</p>  <p>C13168-A</p>	<p>2 Connect a jumper wire between GEM C238-10, circuit 975 (BK/Y), and ground.</p> <ul style="list-style-type: none"> • Does 4x4 low indicator illuminate? <p>→ Yes GO to H22.</p> <p>→ No REPLACE the instrument cluster. CLEAR the DTCs. TEST the system for normal operation.</p>

TEST CONDITIONS	TEST DETAILS/RESULTS/ACTIONS
<p>H22 CHECK CIRCUIT 975 (BR/Y) FOR SHORT TO GROUND</p>  <p>Instrument Cluster C236</p> <p>GC0986-A</p>	<p>3 Measure the resistance between GEM C241-10, circuit 975 (BR/Y), and ground.</p> <ul style="list-style-type: none"> • Is the resistance greater than 10,000 ohms? <p>→ Yes GO to H23.</p> <p>→ No REPAIR circuit 975 (BR/Y). CLEAR the DTCs. TEST the system for normal operation.</p>
<p>H23 CHECK CIRCUIT 975 (BR/Y) FOR SHORT TO POWER</p>  <p>C13169-A</p>	<p>3 Measure the voltage between GEM C241-10, circuit 975 (BR/Y), and ground.</p> <ul style="list-style-type: none"> • Is any voltage indicated? <p>→ Yes REPAIR circuit 975 (BR/Y). CLEAR the DTCs. TEST the system for normal operation.</p> <p>→ No GO to H24.</p>

TEST CONDITIONS	TEST DETAILS/RESULTS/ACTIONS
<p>H24 CHECK CIRCUIT 784 (LB/BK) FOR OPEN</p>  <p style="text-align: center;">C13170-A</p>	<p>3 Measure the resistance between GEM C239-16, circuit 784 (LB/BK), and 4WD indicator switch C189, circuit 784 (LB/BK).</p> <ul style="list-style-type: none"> • Is the resistance less than 5 ohms? <p>→ Yes GO to H25.</p> <p>→ No REPAIR circuit 784 (LB/BK). CLEAR the DTCs. TEST the system for normal operation.</p>
<p>H25 CHECK CIRCUIT 784 (LB/BK) FOR SHORT TO POWER</p>  <p style="text-align: center;">GC0987-A</p>	<p>2 Measure the voltage between GEM C239-16, circuit 784 (LB/BK), and ground.</p> <ul style="list-style-type: none"> • Is any voltage indicated? <p>→ Yes REPAIR circuit 784 (LB/BK). CLEAR the DTCs. TEST the system for normal operation.</p> <p>→ No REPLACE the GEM. CLEAR the DTCs. TEST the system for normal operation.</p>

Condition	Possible Source	Action
<ul style="list-style-type: none"> • 4WD HIGH Does Not Engage at Speed Properly (Driveline Does Not Synchronize Properly), but Does Engage at Rest 	<ul style="list-style-type: none"> • MSOF switch/circuit. • MSOF electric clutch relay/circuit. • MSOF transfer case electric clutch. • MSOF transfer case clutch armature. 	<ul style="list-style-type: none"> • GO to Pinpoint Test F.
<ul style="list-style-type: none"> • Front Axle Not Engaging Properly; Transfer Case Engagement OK 	<ul style="list-style-type: none"> • 4x4 solenoid/circuit. • 4x2 solenoid/circuit. • Vacuum circuit. 	<ul style="list-style-type: none"> • GO to Pinpoint Test G.
<ul style="list-style-type: none"> • 4x4 or LOW Range Indicator Not Operating Properly 	<ul style="list-style-type: none"> • Fuse(s). • Bulb/circuit. • MSOF switch/circuit. • Transmission range (TR) sensor. 	<ul style="list-style-type: none"> • GO to Pinpoint Test H.