

Computers and Control Systems: Pinpoint Tests

Test DC: Mass Air Flow (MAF) Sensor

PINPOINT TEST DC: MASS AIR FLOW (MAF) SENSOR

Mass Air Flow (MAF) Sensor


DC

This pinpoint test is intended to diagnose the following:

- Mass Air Flow Sensor (12B579).
- Harness circuits: MAF SIG, MAF RTN, Vehicle Power (VPWR), Power Ground (PWRGND), IAT and SIGRTN.
- Powertrain control module (PCM) (12A650).


Mass Air Flow/Intake Air Temperature (MAF/IAT) Sensor Connector

A



A0077549

B



A0077520

Vehicle	Connector	Circuit	Pin
Aviator, Escape 3.0L, Explorer SportTrac, F-150 4.6L	A	IAT	1
		SIGRTN	6
		MAF RTN	3
		MAF	2
		PWRGND VPWR	4 5
F-150 4.2L	A	MAF RTN	3
		MAF	2
		PWRGND	4
		VPWR	5
All other vehicles	B	IAT	1
		SIGRTN	2
		MAF RTN	4
		MAF	3
		PWRGND	5
		VPWR	6

Note, Connectors

Mass Air Flow (MAF) Sensor**DC****Powertrain Control Module (PCM) Connector**

For PCM connector views or reference values, refer to Reference Values.

Vehicle	Connector	Circuit	Pin
Aviator, LS, Thunderbird	150 (60-32-58) Pin	MAF MAF RTN	B31 B38
E-Series, F-Super Duty, Mustang	170 Pin	MAF MAF RTN	E25 E26
Excursion, Explorer SportTrac, Freestar/Monterey, Ford GT, Ranger, Sable, Taurus	104 Pin	MAF MAF RTN	88 36
Expedition, F-150, Navigator	190 Pin	MAF MAF RTN	B41 B42
All other vehicles	150 (50-50-50) Pin	MAF MAF RTN	B32 B43

BAROMETRIC PRESSURE REFERENCE CHART

Barometric Pressure (in. Hg)	Barometric Pressure (kPa)	BARO/MAP PID (Hz)	Altitude Above Sea Level (ft)
3.5	11.8	89.3	
5	16.9	92.8	
10	33.8	104.6	
15	50.7	117.0	14,000
20	67.5	129.6	10,000
21	70.9	132.5	9,000
22	74.3	135.4	8,000
23	77.7	138.3	7,000
24	81.1	141.1	6,000
25	84.4	144.0	5,000
26	87.8	146.9	4,000
27	91.2	149.8	3,000
28	94.6	152.8	2,000
29	97.9	155.8	1,000
30	101.3	158.9	0 (sea level)
31	104.7	162.0	
31.875	107.7	164.7	

Mass Air Flow (MAF) Sensor

DC

Test Step		Results / Action to Take
DC1	DTC P1101: CHECK FOR MAF SENSOR CONTINUOUS MEMORY DTCS	
	<ul style="list-style-type: none"> Retrieve CMDTCs. Is a continuous memory MAF DTC present with the KOER DTC P1101? 	Yes GO to DC2 . No Key in OFF position. GO to DC4 .
DC2	VERIFY CONTINUOUS MEMORY DTC P0102	
	<ul style="list-style-type: none"> Is a continuous memory DTC P0102 present with the KOER DTC P1101? 	Yes GO to DC4 . No GO to DC3 .
DC3	VERIFY CONTINUOUS MEMORY DTC P0103	
	<ul style="list-style-type: none"> Is a continuous memory DTC P0103 present with the KOER DTC P1101? 	Yes GO to DC20 . No All other continuous memory DTCs: DISREGARD the current diagnostic trouble code (DTC) at this time. ADDRESS the next DTC. GO to Diagnostic Trouble Code (DTC) Charts and Descriptions.
DC4	KOER AND CONTINUOUS MEMORY DTCS P0102, P0104 OR P1101: CHECK THE INTAKE AIR SYSTEM FOR LEAKS, OBSTRUCTIONS, AND DAMAGE	
	<ul style="list-style-type: none"> Check the air inlet system (air cleaner, housing, ductwork) for obstructions or blockage. Check for broken/loose air outlet tube clamps (throttle body and air cleaner assembly ends), cracks/holes in the air outlet tube, and worn gaskets between the MAF sensor and the air cleaner assembly. Verify the MAF sensor is connected. Repair as necessary. Are there any concerns found during the visual inspection? 	Yes Key in OFF position. REPAIR as necessary. No GO to DC5 .
DC5	CHECK THE MAF PID	
	<ul style="list-style-type: none"> Run the engine up to 1,500 RPM for 5 seconds, then bring it back to idle. Access the PCM and monitor the MAF V PID. Is the voltage less than 0.23 V? 	Yes Key in OFF position. GO to DC8 . No Key in OFF position. GO to DC6 .

DC1-DC5

Mass Air Flow (MAF) Sensor**DC**

Test Step		Results / Action to Take				
DC6	CHECK THE MAF SIGNAL SENT TO THE PCM Note: DTC P1101 can be generated by a low charged vehicle battery or the garage exhaust ventilation system. Charge the battery as necessary, then remove the ventilation system and properly vent to the outside atmosphere. Check the air inlet system (air cleaner, housing, ductwork) for obstructions or blockage. Rerun the KOEO self-test. <ul style="list-style-type: none"> • MAF/IAT Sensor connector connected. • Key in ON position. • Access the PCM and monitor the MAF V PID. • Is the voltage less than 0.2 V? 	Yes GO to DC7 . No Key in OFF position. GO to DC8 .				
DC7	CHECK THE MAF SIGNAL SENT TO THE PCM <ul style="list-style-type: none"> • Key on engine running. • Access the PCM and monitor the MAF V PID. • Is the voltage between 0.46 V - 2.44 V? 	Yes Unable to identify the fault at this time. GO to Z1 . No Key in OFF position. GO to DC8 .				
DC8	CHECK THE VPWR TO THE MAF SENSOR <ul style="list-style-type: none"> • MAF/IAT Sensor connector disconnected. • Key in ON position. • Measure the voltage between: <table border="1" data-bbox="305 1024 857 1142"> <tr> <td>(+) MAF/IAT Sensor Connector, Harness Side</td> <td>(-) Vehicle Battery</td> </tr> <tr> <td>VPWR</td> <td>Negative terminal</td> </tr> </table> • Is the voltage greater than 10.5 V? 	(+) MAF/IAT Sensor Connector, Harness Side	(-) Vehicle Battery	VPWR	Negative terminal	Yes GO to DC9 . No Key in OFF position. REPAIR the open circuit.
(+) MAF/IAT Sensor Connector, Harness Side	(-) Vehicle Battery					
VPWR	Negative terminal					
DC9	CHECK THE PWRGND CIRCUIT TO MAF SENSOR <ul style="list-style-type: none"> • Measure the voltage between: <table border="1" data-bbox="305 1268 857 1381"> <tr> <td>(+) Vehicle Battery</td> <td>(-) MAF/IAT Sensor Connector, Harness Side</td> </tr> <tr> <td>Positive terminal</td> <td>PWRGND</td> </tr> </table> • Is the voltage greater than 10.5 V? 	(+) Vehicle Battery	(-) MAF/IAT Sensor Connector, Harness Side	Positive terminal	PWRGND	Yes Key in OFF position. GO to DC10 . No Key in OFF position. REPAIR the open circuit.
(+) Vehicle Battery	(-) MAF/IAT Sensor Connector, Harness Side					
Positive terminal	PWRGND					

DC6-DC9

Mass Air Flow (MAF) Sensor

DC

Test Step		Results / Action to Take										
DC10	CHECK FOR SHORTS BETWEEN CIRCUITS IN MAF HARNESS Note: For vehicles with a stand alone MAF sensor (IAT sensor not internal to the MAF sensor), disregard MAF circuit checks to IAT and SIGRTN. <ul style="list-style-type: none"> MAF/IAT Sensor connector disconnected. PCM connector disconnected. Measure the resistance between: <table border="1"> <thead> <tr> <th>(+) MAF/IAT Sensor Connector, Harness Side</th> <th>(-) MAF/IAT Sensor Connector, Harness Side</th> </tr> </thead> <tbody> <tr> <td>MAF</td> <td>PWRGND</td> </tr> <tr> <td>MAF</td> <td>MAF RTN</td> </tr> <tr> <td>MAF</td> <td>SIGRTN</td> </tr> <tr> <td>MAF</td> <td>IAT</td> </tr> </tbody> </table> <ul style="list-style-type: none"> Are the resistances greater than 10K ohms? 	(+) MAF/IAT Sensor Connector, Harness Side	(-) MAF/IAT Sensor Connector, Harness Side	MAF	PWRGND	MAF	MAF RTN	MAF	SIGRTN	MAF	IAT	Yes GO to DC11 . No REPAIR the short circuit.
(+) MAF/IAT Sensor Connector, Harness Side	(-) MAF/IAT Sensor Connector, Harness Side											
MAF	PWRGND											
MAF	MAF RTN											
MAF	SIGRTN											
MAF	IAT											
DC11	CHECK THE MAF RTN CIRCUIT FOR AN OPEN IN THE HARNESS <ul style="list-style-type: none"> Measure the resistance between: <table border="1"> <thead> <tr> <th>(+) PCM Connector, Harness Side</th> <th>(-) MAF/IAT Sensor Connector, Harness Side</th> </tr> </thead> <tbody> <tr> <td>MAF RTN</td> <td>MAF RTN</td> </tr> </tbody> </table> <ul style="list-style-type: none"> Is the resistance less than 5 ohms? 	(+) PCM Connector, Harness Side	(-) MAF/IAT Sensor Connector, Harness Side	MAF RTN	MAF RTN	Yes GO to DC12 . No REPAIR the open circuit.						
(+) PCM Connector, Harness Side	(-) MAF/IAT Sensor Connector, Harness Side											
MAF RTN	MAF RTN											
DC12	CHECK THE MAF RTN CIRCUIT FOR A SHORT TO PWRGND IN THE HARNESS <ul style="list-style-type: none"> Measure the resistance between: <table border="1"> <thead> <tr> <th>(+) MAF/IAT Sensor Connector, Harness Side</th> <th>(-) MAF/IAT Sensor Connector, Harness Side</th> </tr> </thead> <tbody> <tr> <td>MAF RTN</td> <td>PWRGND</td> </tr> </tbody> </table> <ul style="list-style-type: none"> Is the resistance greater than 10K ohms? 	(+) MAF/IAT Sensor Connector, Harness Side	(-) MAF/IAT Sensor Connector, Harness Side	MAF RTN	PWRGND	Yes GO to DC13 . No REPAIR the short circuit to GND.						
(+) MAF/IAT Sensor Connector, Harness Side	(-) MAF/IAT Sensor Connector, Harness Side											
MAF RTN	PWRGND											
DC13	CHECK THE MAF CIRCUIT FOR A SHORT TO PWRGND IN THE PCM <ul style="list-style-type: none"> PCM connector connected. Measure the resistance between: <table border="1"> <thead> <tr> <th>(+) MAF/IAT Sensor Connector, Harness Side</th> <th>(-) MAF/IAT Sensor Connector, Harness Side</th> </tr> </thead> <tbody> <tr> <td>MAF</td> <td>PWRGND</td> </tr> </tbody> </table> <ul style="list-style-type: none"> Is the resistance greater than 10K ohms? 	(+) MAF/IAT Sensor Connector, Harness Side	(-) MAF/IAT Sensor Connector, Harness Side	MAF	PWRGND	Yes GO to DC14 . No INSTALL a new PCM. REFER to Diagnostic Methods, Flash Electrically Erasable Programmable Read Only Memory (EEPROM).						
(+) MAF/IAT Sensor Connector, Harness Side	(-) MAF/IAT Sensor Connector, Harness Side											
MAF	PWRGND											

DC10-DC13

Mass Air Flow (MAF) Sensor

DC

Test Step		Results / Action to Take						
DC14	CHECK THE MAF CIRCUIT VOLTAGE CYCLING INTEGRITY <ul style="list-style-type: none"> Diagnostic tool connector connected. Key in ON position. Access the MAF V PID. Connect a 5 amp fused jumper wire between the following: <table border="1"> <thead> <tr> <th>Point A MAF/IAT Sensor Connector, Harness Side</th> <th>Point B MAF/IAT Sensor Connector, Harness Side</th> </tr> </thead> <tbody> <tr> <td>MAF RTN</td> <td>PWRGND</td> </tr> <tr> <td>MAF</td> <td>VPWR</td> </tr> </tbody> </table> <ul style="list-style-type: none"> Take the PID reading while both jumpers are installed. Remove the VPWR jumper while observing the MAF V PID. Does the MAF V PID change from greater than 4.50 volts to less than 0.26 volt when the VPWR jumper is removed? 	Point A MAF/IAT Sensor Connector, Harness Side	Point B MAF/IAT Sensor Connector, Harness Side	MAF RTN	PWRGND	MAF	VPWR	Yes Key in OFF position. REMOVE the jumper wire(s). If OK, INSTALL a new MAF sensor. RESET the keep alive memory (KAM). REFER to Diagnostic Methods, Resetting The Keep Alive Memory (KAM). No Key in OFF position. REMOVE the jumper wire(s). GO to DC15.
Point A MAF/IAT Sensor Connector, Harness Side	Point B MAF/IAT Sensor Connector, Harness Side							
MAF RTN	PWRGND							
MAF	VPWR							
DC15	CHECK THE MAF CIRCUIT FOR AN OPEN IN THE HARNESS <ul style="list-style-type: none"> PCM connector disconnected. Measure the resistance between: <table border="1"> <thead> <tr> <th>(+) PCM Connector, Harness Side</th> <th>(-) MAF/IAT Sensor Connector, Harness Side</th> </tr> </thead> <tbody> <tr> <td>MAF</td> <td>MAF</td> </tr> </tbody> </table> <ul style="list-style-type: none"> Is the resistance less than 5 ohms? 	(+) PCM Connector, Harness Side	(-) MAF/IAT Sensor Connector, Harness Side	MAF	MAF	Yes GO to DC16. No REPAIR the open circuit.		
(+) PCM Connector, Harness Side	(-) MAF/IAT Sensor Connector, Harness Side							
MAF	MAF							
DC16	CHECK THE PWRGND CIRCUIT FOR AN OPEN IN THE HARNESS <ul style="list-style-type: none"> PCM connector disconnected. Measure the resistance between: <table border="1"> <thead> <tr> <th>(+) MAF/IAT Sensor Connector, Harness Side</th> <th>(-) Vehicle Battery</th> </tr> </thead> <tbody> <tr> <td>PWRGND</td> <td>Negative terminal</td> </tr> </tbody> </table> <ul style="list-style-type: none"> Is the resistance less than 5 ohms? 	(+) MAF/IAT Sensor Connector, Harness Side	(-) Vehicle Battery	PWRGND	Negative terminal	Yes GO to DC17. No REPAIR the open circuit.		
(+) MAF/IAT Sensor Connector, Harness Side	(-) Vehicle Battery							
PWRGND	Negative terminal							

DC14-DC16

Mass Air Flow (MAF) Sensor

DC

Test Step		Results / Action to Take				
DC17	CHECK THE MAF RTN CIRCUIT FOR AN OPEN IN THE HARNESS <ul style="list-style-type: none"> Measure the resistance between: <table border="1" data-bbox="310 443 862 562"> <tr> <td>(+) PCM Connector, Harness Side</td> <td>(-) MAF/IAT Sensor Connector, Harness Side</td> </tr> <tr> <td>MAF RTN</td> <td>MAF RTN</td> </tr> </table> Is the resistance less than 5 ohms? 	(+) PCM Connector, Harness Side	(-) MAF/IAT Sensor Connector, Harness Side	MAF RTN	MAF RTN	Yes INSTALL a new PCM. REFER to Diagnostic Methods, Flash Electrically Erasable Programmable Read Only Memory (EEPROM). No REPAIR the open circuit.
(+) PCM Connector, Harness Side	(-) MAF/IAT Sensor Connector, Harness Side					
MAF RTN	MAF RTN					
DC18	DTC P1100: CHECK THE MAF CIRCUIT FOR INTERMITTENT VOLTAGE TO THE PCM <ul style="list-style-type: none"> Check for broken/loose air outlet tube clamps (throttle body and air cleaner assembly ends), cracks/holes in the air outlet tube, and worn gaskets between the MAF sensor and the air cleaner assembly. Verify the MAF sensor is connected. Key on engine running. Access the PCM and monitor the MAF V PID. If idle is not stable, refer to Symptom Charts. Run the engine up to 1,500 RPM for 5 seconds, then bring it back to idle. Run the engine up to 1,500 RPM for 5 seconds, then bring it back to idle. Access the PCM and monitor the MAF V PID. Lightly tap on the MAF sensor and wiggle the harness connector to simulate road shock. Does the MAF PID go below 0.23 volt or above 4.6 volts? 	Yes Key in OFF position. INSPECT the MAF sensor connector. If OK, INSTALL a new MAF sensor. RESET the keep alive memory (KAM). REFER to Diagnostic Methods, Resetting The Keep Alive Memory (KAM). No GO to DC19.				
DC19	CHECK THE MAF CIRCUIT FOR AN INTERMITTENT OPEN OR SHORTS <ul style="list-style-type: none"> Key on engine running. Access the PCM and monitor the MAF V PID. Wiggle, shake, and bend small sections of the wiring harness while working from the sensor to the PCM. Does the MAF PID go below 0.23 volt or above 4.6 volts? 	Yes Key in OFF position. REPAIR as necessary. RESET the keep alive memory (KAM). REFER to Diagnostic Methods, Resetting The Keep Alive Memory (KAM). No Key in OFF position. Unable to duplicate or identify the fault at this time.				

DC17-DC19

Mass Air Flow (MAF) Sensor

DC

Test Step		Results / Action to Take				
DC20	DTC P0103: CHECK THE MAF SENSOR SCREEN FOR CONTAMINATION Note: DTC P0103 can be generated by foreign material blocking the MAF sensor screen, causing an air flow restriction. <ul style="list-style-type: none"> • Check the MAF sensor screen for contamination or blockage. • Check the air cleaner element and air tubes for proper installation and sealing. • Were any problems found? 	Yes REPAIR as necessary. RERUN Self-Test. No GO to DC21 .				
DC21	DTC P0103: CHECK THE MAF SENSOR SIGNAL HIGH INPUT TO THE PCM <ul style="list-style-type: none"> • Key in ON position. • Access the PCM and monitor the MAF V PID. • Is the voltage greater than 2.44 V? 	Yes Key in OFF position. GO to DC22 . No GO to DC24 .				
DC22	CHECK THE MAF SENSOR SIGNAL SENT TO THE PCM <ul style="list-style-type: none"> • MAF/IAT Sensor connector disconnected. • Connect a 5 amp fused jumper wire between the following: <table border="1" data-bbox="300 961 857 1081"> <thead> <tr> <th>Point A MAF/IAT Sensor Connector, Harness Side</th> <th>Point B MAF/IAT Sensor Connector, Harness Side</th> </tr> </thead> <tbody> <tr> <td>MAF RTN</td> <td>PWRGND</td> </tr> </tbody> </table> <ul style="list-style-type: none"> • Key in ON position. • Access the PCM and monitor the MAF V PID. • Is the voltage less than 0.1 V? 	Point A MAF/IAT Sensor Connector, Harness Side	Point B MAF/IAT Sensor Connector, Harness Side	MAF RTN	PWRGND	Yes Key in OFF position. REMOVE the jumper wire(s). CHECK the MAF sensor electrical connector for damage, corrosion, and water ingress. If OK, INSTALL a new MAF sensor. RESET the keep alive memory (KAM). REFER to Diagnostic Methods, Resetting The Keep Alive Memory (KAM). No Key in OFF position. GO to DC23 .
Point A MAF/IAT Sensor Connector, Harness Side	Point B MAF/IAT Sensor Connector, Harness Side					
MAF RTN	PWRGND					
DC23	CHECK THE MAF CIRCUIT FOR A SHORT TO POWER <ul style="list-style-type: none"> • PCM connector disconnected. • Key in ON position. • Measure the voltage between: <table border="1" data-bbox="300 1438 857 1537"> <thead> <tr> <th>(+) PCM Connector, Harness Side</th> <th>(-)</th> </tr> </thead> <tbody> <tr> <td>MAF</td> <td>Ground</td> </tr> </tbody> </table> <ul style="list-style-type: none"> • Is the voltage less than 1 V? 	(+) PCM Connector, Harness Side	(-)	MAF	Ground	Yes GO to DC25 . No Key in OFF position. REPAIR the short circuit to PWR.
(+) PCM Connector, Harness Side	(-)					
MAF	Ground					

DC20-DC23

Mass Air Flow (MAF) Sensor**DC**

Test Step		Results / Action to Take
DC24	CHECK THE MAF SIGNAL SENT TO THE PCM	
	<ul style="list-style-type: none"> • Key on engine running. • Monitor the MAF signal voltage while increasing the engine RPM from idle to approximately 2,500 RPM, and then back to idle. • Access the PCM and monitor the MAF V PID. • Is the voltage between 0.23 V - 4.6 V? 	<p>Yes Key in OFF position. Intermittent concern. GO to Z1.</p> <p>No Key in OFF position. GO to DC22.</p>
DC25	VERIFY THE IDLE CONCERN	
	<ul style="list-style-type: none"> • PCM connector connected. • MAF/IAT Sensor connector connected. • Key on engine running. • Is there an idle concern present? 	<p>Yes DISREGARD DTC P0103 at this time. Concern is elsewhere. RETURN to Symptom Charts for further direction.</p> <p>No INSTALL a new PCM. REFER to Diagnostic Methods, Flash Electrically Erasable Programmable Read Only Memory (EEPROM).</p>
DC26	DTC P0171, P0172, P0174, P0175, P1131, P1132, P1151, P1152, P1130, P1150, P2195, P2196, P2197, P2198: (OR LEAN DRIVEABILITY CONCERNS) CHECK THE CONDITIONS RELATED TO THE MAF SENSOR	
	<ul style="list-style-type: none"> • Check the air inlet system (air cleaner, housing, ductwork) for obstructions or blockage. • Check for broken/loose air outlet tube clamps (throttle body and air cleaner assembly ends), cracks/holes in the air outlet tube, and worn gaskets between the MAF sensor and the air cleaner assembly. Verify the MAF sensor is connected. • Are any problems found? 	<p>Yes REPAIR as necessary. RESET the keep alive memory (KAM). REFER to Diagnostic Methods, Resetting The Keep Alive Memory (KAM).</p> <p>No GO to DC27.</p>

DC24-DC26

Mass Air Flow (MAF) Sensor

DC

	Test Step	Results / Action to Take
DC27	DTC P0171, P0172, P0174, P0175, P1131, P1132, P1151, P1152, P1130, P1150, P2195, P2196, P2197, P2198: (OR LEAN DRIVEABILITY CONCERNS) CHECK CONDITIONS RELATED TO THE MAF SENSOR	
	<p>Note: Most weather reports include a local barometric pressure that has been corrected to sea level. However, the BARO PID reports the actual barometric pressure for the altitude where the vehicle is being diagnosed. Local weather conditions (high or low pressure areas) will change the local barometric pressure by several inches of mercury.</p> <ul style="list-style-type: none"> • Key on engine running. • Access the PCM and monitor the LONGFT1, LONGFT2, MAF V and BARO PIDs. • Check that the BARO PID is approximately the same as the barometric pressure reading for the location, day, and altitude where the vehicle is being diagnosed. <ul style="list-style-type: none"> — The BARO PID values in Keep Alive Memory require updating at high throttle openings. If the vehicle is driven down from higher altitudes for diagnosis, carry out 3 or 4 heavy accelerations at greater than half-throttle to allow the BARO PID to update. — The BARO PID must be within +/- 6 Hz. (+/- 2 in Hg.) of the altitude value in Barometric Pressure Reference Chart (at the beginning of this pinpoint test). — Make BARO PID comparisons to the Barometric Pressure Reference Chart or daily airport barometric pressure reports, if available. • Check that the LONGFT1 and LONGFT2 PIDs for all injector banks at idle are not more negative than -12%. • Check that the MAF V PID at idle and neutral is not greater than 30% of the normal MAF V listed in Reference Values (or not greater than 1.1 volts). • Are 2 of the 3 checks OK? 	<p>Yes GO to DC29.</p> <p>No Key in OFF position. GO to DC28.</p>
DC28	CHECK TO ISOLATE MAF SENSOR FROM LEAN DRIVEABILITY OCCURRENCE <ul style="list-style-type: none"> • Due to increasingly stringent emission/OBD requirements, a fuel system DTC on some vehicles can be generated without a noticeable driveability concern with or without the MAF sensor disconnected. Under these conditions, if the BARO_V, LONGFT1, LONGFT2, and MAF PIDs indicate a MAF sensor concern, install a new MAF sensor. • MAF/IAT Sensor connector disconnected. • Key on engine running. • Drive the vehicle on the road. • Is the lean driveability symptom (lack of power, spark knock/detonation, buck/jerk or hesitation/surge on acceleration) gone? 	<p>Yes If OK, INSTALL a new MAF/IAT sensor. RESET the keep alive memory (KAM). REFER to Diagnostic Methods, Resetting The Keep Alive Memory (KAM).</p> <p>No GO to DC29.</p>

Mass Air Flow (MAF) Sensor**DC**

Test Step		Results / Action to Take
DC29	VERIFY THE DTC <ul style="list-style-type: none">Are any of the following DTCs present: P0171, P0172, P0174, P0175, P1130, P1131, P1132, P1150, P1151, P1152, P2195, P2196, P2197, or P2198?	Yes GO to H22. No Concern is elsewhere. RETURN to Symptom Charts for further direction.

DC29