

Computers and Control Systems: Pinpoint Tests

Test A: No Start

PINPOINT TEST A: NO START

No Start

A

⚠ WARNING: Stop this test at the first sign of a fuel leak and repair as required. No open flame. No smoking during fuel delivery checks. Failure to follow these instructions may result in personal injury.


This pinpoint test is intended to diagnose the following:

- spark (as related to electronic engine control)
- powertrain control module (PCM) (12A650)

Throttle Position (TP) Sensor Connector

A

B



A0077554

A0077555


Vehicle	Connector	Pin	Circuit
Escape 2.3L, Focus, Mariner 2.3L, Ranger 2.3L	A	1 3	SIGRTN VREF
All other vehicles	B	3 1	SIGRTN VREF

No Start

A


Electronic Throttle Body Throttle Position Sensor (ETBTPS) Connector

A




A0077520

B



A0094772

C



A0077519


Vehicle	Connector	Pin	Circuit
F-150 4.2L	A	2 3	ETCRTN ETCREF
Five Hundred, Freestyle, Fusion 3.0L, Milan 3.0L, Montego, Zephyr	B	4 5	ETCRTN ETCREF
Fusion 2.3L, Milan 2.3L	B	3 5	ETCRTN ETCREF
All other vehicles	C	3 2	ETCRTN ETCREF

Electronic Throttle Body Throttle Position Sensor (ETBTPS) Connector

No Start

A

Data Link Connector (DLC)



A0077513

Pin	Circuit
13	FEPS (Flash EEPROM Programming Signal)

Test Step		Results / Action to Take
A1	ATTEMPT TO CRANK THE ENGINE Note: Verify the inertia fuel shutoff (IFS) switch is set (button pushed in). Refer to the Owner's Literature for location. • Does the engine crank?	Yes GO to A2. No REFER to Starting System.
A2	IDENTIFY THE TYPE OF NO START Note: The purpose of this test step is to identify intermittent no starts in order to determine the proper repair procedure. • Does the vehicle start?	Yes The vehicle has an intermittent no start. GO to Pinpoint Test Z. No GO to A3.
A3	DETERMINE THE THROTTLE TYPE • Is vehicle equipped with electronic throttle control?	Yes GO to A5. No GO to A4.

Data Link Connector (DLC) And A1-A3


No Start

A

Test Step		Results / Action to Take				
A4	CHECK THE VREF VOLTAGE TO TP SENSOR <ul style="list-style-type: none"> Key in OFF position. TP Sensor connector disconnected. Key ON, engine OFF. Measure the voltage between: <table border="1"> <tr> <td>(+) TP Sensor Connector, Harness Side</td> <td>(-) TP Sensor Connector, Harness Side</td> </tr> <tr> <td>VREF</td> <td>SIGRTN</td> </tr> </table> <ul style="list-style-type: none"> Is the voltage between 4.5 - 5.5 V? 	(+) TP Sensor Connector, Harness Side	(-) TP Sensor Connector, Harness Side	VREF	SIGRTN	Yes GO to A6 . No GO to Pinpoint Test C.
(+) TP Sensor Connector, Harness Side	(-) TP Sensor Connector, Harness Side					
VREF	SIGRTN					
A5	CHECK VREF VOLTAGE TO ETBTPS SENSOR <ul style="list-style-type: none"> Key in OFF position. ETBTPS connector disconnected. Key ON, engine OFF. Measure the voltage between: <table border="1"> <tr> <td>(+) ETBTPS Connector, Harness Side</td> <td>(-) ETBTPS Connector, Harness Side</td> </tr> <tr> <td>ETCREF</td> <td>ETCRTN</td> </tr> </table> <ul style="list-style-type: none"> Is the voltage between 4.5 - 5.5 V? 	(+) ETBTPS Connector, Harness Side	(-) ETBTPS Connector, Harness Side	ETCREF	ETCRTN	Yes GO to A6 . No GO to Pinpoint Test C.
(+) ETBTPS Connector, Harness Side	(-) ETBTPS Connector, Harness Side					
ETCREF	ETCRTN					
A6	CHECK THE FLASH EEPROM PROGRAMMING SIGNAL (FEPS) CIRCUIT FOR A SHORT TO VOLTAGE IN THE HARNESS <ul style="list-style-type: none"> Key in OFF position. TP Sensor connector connected. ETBTPS connector connected. Key ON, engine OFF. Measure the voltage between: <table border="1"> <tr> <td>(+) DLC, Harness Side</td> <td>(-) Vehicle Battery</td> </tr> <tr> <td>FEPS - Pin 13</td> <td>Negative terminal</td> </tr> </table> <ul style="list-style-type: none"> Is the voltage greater than 9 V? 	(+) DLC, Harness Side	(-) Vehicle Battery	FEPS - Pin 13	Negative terminal	Yes REPAIR the short circuit. CLEAR the DTCs. REPEAT the self-test. No GO to A7 .
(+) DLC, Harness Side	(-) Vehicle Battery					
FEPS - Pin 13	Negative terminal					
A7	CHECK THE RPM IN THE PCM <p>Note: The diagnostic tool must be connected to a reliable voltage source that is powered with the key in the START position (such as directly to the vehicle battery). Also verify that the vehicle battery is fully charged.</p> <p>Note: Normal engine cranking speed is between 150 RPM and 350 RPM.</p> <ul style="list-style-type: none"> Access the PCM and monitor the RPM PID. Crank the engine while viewing the RPM PID. Is the RPM between 150 RPM - 350 RPM? 	Yes GO to A8 . No For base engine concerns, REFER to Engine. For all others, GO to JD2 .				

No Start

A

Test Step		Results / Action to Take
A8	CHECK THE PCM DRIVER SIGNAL TO THE COILS	Yes GO to A9 . No For Coil-on-plug (COP) ignition testing GO to JB2 . For Coil pack ignition testing GO to JC2 .
	<p>Note: Test lamp bulb filament wattages vary widely. The intensity and duration of blinking depends on the test lamp being used.</p> <ul style="list-style-type: none"> • Connect a test lamp between B+ and each coil driver circuit at the harness connector. • Crank the engine. • Does the test lamp blink consistently for each coil driver (1 blink per engine revolution)? 	
A9	CHECK THE FUEL PRESSURE	Yes GO to A10 . No GO to Pinpoint Test HC.
	<p> WARNING: The fuel system remains pressurized when the engine is not running. To prevent injury or fire, use caution when working on the fuel system. Refer to the fuel system WARNING information at the beginning of Pinpoint Test HC. Failure to follow these instructions may result in personal injury.</p> <p>Note: For vehicles not equipped with a fuel rail Schrader valve, a T-adaptor with hoses must be installed on the fuel rail before proceeding with this test.</p> <p>Note: While activating the fuel pump on an electronic returnless fuel system a brief pressure spike may occur.</p> <ul style="list-style-type: none"> • Key in OFF position. • Relieve the fuel pressure. Refer to Fuel Delivery and Air Induction for the Fuel System Pressure Release procedure. • Connect the fuel pressure gauge to the Schrader valve using the appropriate fuel pressure test hose and adaptor. • Key ON, engine OFF. • Enter output test mode. Refer to Diagnostic Methods, Output Test Mode (OTM). • Activate the fuel pump to obtain maximum fuel pressure. • Is the fuel pressure within specification (refer to the fuel pressure chart in Pinpoint Test HC)? 	
A10	CHECK THE FUEL PRESSURE LEAKDOWN	Yes GO to A11 . No GO to Pinpoint Test HC.
	<ul style="list-style-type: none"> • Key ON, engine OFF. • Enter output test mode. Refer to Diagnostic Methods, Output Test Mode (OTM). • Activate the fuel pump to obtain maximum fuel pressure. • Exit output test mode. • Monitor the fuel pressure. • Verify the fuel pressure remains within 34 kPa (5 psi) of the maximum pressure for 1 minute after turning the pump off. • Does fuel pressure remain within 34 kPa (5 psi)? 	

No Start

A

Test Step		Results / Action to Take
A11	CHECK THE FUEL INJECTORS FOR VOLTAGE Note: A no start condition typically exists only if greater than half of the fuel injectors are without voltage. Check at least 2 fuel injectors, 1 on each bank on V type engines. <ul style="list-style-type: none"> • Key in OFF position. • Disconnect 2 fuel injectors. • Key ON, engine OFF. • Measure the VPWR voltage at each fuel injector harness connector. • Is the voltage greater than 10 volts? 	Yes GO to A12 . No REPAIR the VPWR circuit. CLEAR the DTCs. REPEAT the self-test.
A12	CHECK THE FUEL INJECTORS' ABILITY TO DELIVER FUEL <ul style="list-style-type: none"> • Cycle the key several times to charge the fuel system. • IFS switch disconnected. • Monitor the fuel pressure gauge while cranking the engine for at least 5 seconds. • Is there a pressure drop greater than 34 kPa (5 psi) while cranking the engine? 	Yes The electronic engine control (EEC) system is not the cause of the no start. The concern is elsewhere. RETURN to Symptom Charts for further direction. No GO to A13 .
A13	CHECK FOR CORRECT PCM OPERATION <ul style="list-style-type: none"> • Disconnect all the PCM connectors. • Visually inspect for: <ul style="list-style-type: none"> — pushed out pins — corrosion • Connect all the PCM connectors and make sure they seat correctly. • Carry out the PCM self-test and verify the concern is still present. • Is the concern still present? 	Yes INSTALL a new PCM. REFER to Diagnostic Methods, Flash Electrically Erasable Programmable Read Only Memory (EEPROM). No The system is operating correctly at this time. The concern may have been caused by a loose or corroded connector.