


## Antilock Brakes / Traction Control Systems: Testing and Inspection



Anti-Lock Brake System Troubleshooting Chart

### Description of On-Board Diagnostics

Two warning lamps are located on the instrument panel to alert the driver to a system malfunction. The red brake warning lamp is used to indicate conventional brake system malfunctions such as low fluid level, parking brake applied and low vacuum conditions (diesel engines only). The yellow anti-lock system warning lamp is used to indicate proper warning lamp circuit operation (2 second illumination with ignition On or engine cranking). If yellow lamp comes on while vehicle is being driven, it is alerting the driver of an anti-lock system malfunction and yellow lamp can then be used to access flashout codes. This self-test feature contains 13 codes to indicate area of system malfunction. When a malfunction is detected within the system,

the computer module will shutdown the anti-lock system and illuminate the yellow warning lamp on the instrument panel. This will permit normal braking and at the same time will store a code in the system memory which can be retrieved by grounding the diagnostic connector of the computer module and counting the number of flashes of the yellow light. If the ignition is turned off before diagnosis is performed, the code stored will be lost. In this case, the vehicle must be started and driven to reproduce the condition. If more than one fault exists, only the first code recorded will be displayed. Additional codes will output only after the first fault has been corrected.

CONDITION	ACTION TO TAKE
No Flashout Code	See Flashout Code 0
Yellow REAR ANTILOCK Light Flashes 1 Time This Code Should Not Occur	See Flashout Code 1
Yellow REAR ANTILOCK Light Flashes 2 Times Open Isolate Circuit	See Flashout Code 2
Yellow REAR ANTILOCK Light Flashes 3 Times Open Dump Circuit	See Flashout Code 3
Yellow REAR ANTILOCK Light Flashes 4 Times Red Brake Warning Light Illuminated RABS Valve Switch Closed or Open Dump Valve	See Flashout Code 4
Yellow REAR ANTILOCK Light Flashes 5 Times System Dumps Too Many Times in 2WD (2WD and 4WD vehicles) Condition Occurs While Making Normal or Hard Stops. Rear Brake May Lock	See Flashout Code 5
Yellow REAR ANTILOCK Light Flashes 6 Times (Sensor Signal Rapidly Cuts In and Out) Condition Only Occurs While Driving	See Flashout Code 6
Yellow REAR ANTILOCK Light Flashes 7 Times No Isolate Valve Self Test	See Flashout Code 7
Yellow REAR ANTILOCK Light Flashes 8 Times No Dump Valve Self Test	See Flashout Code 8
Yellow REAR ANTILOCK Light Flashes 9 Times High Sensor Resistance	See Flashout Code 9
Yellow REAR ANTILOCK Light Flashes 10 Times Low Sensor Resistance	See Flashout Code 10
Yellow REAR ANTILOCK Light Flashes 11 Times Stop Lamp Switch Circuit Defective. Condition Indicated Only When Driving Above 35 mph	See Flashout Code 11
Yellow REAR ANTILOCK Light Flashes 12 Times Low Brake Fluid Level Detected During Antilock Stop	See Flashout Code 12
Yellow REAR ANTILOCK Light Flashes 13 Times Speed Processor Check	See Flashout Code 13
Yellow REAR ANTILOCK Light Flashes 14 Times Program Check	See Flashout Code 14
Yellow REAR ANTILOCK Light Flashes 15 Times Memory Failure	See Flashout Code 15
Yellow REAR ANTILOCK Light Flashes 16 Times or More 16 or More Flashes Should Not Occur	See Flashout Code 16

**NOTE:** Refer to Obtaining the Flashout Code in this Section for procedure to obtain flashout code.

**CAUTION:** WHEN CHECKING RESISTANCE IN THE RABS SYSTEM, ALWAYS DISCONNECT THE BATTERY. IMPROPER RESISTANCE READINGS MAY OCCUR WITH THE VEHICLE BATTERY CONNECTED.

Fig. 46 Flashout Code Chart


When only the yellow anti-lock brake system warning lamp is illuminated during vehicle operation (red brake system warning lamp is off), a service condition is present in the anti-lock brake system. At this point, a code will be stored in the computer module until the ignition switch is placed in the Off position. It is recommended that the fault code be obtained before the ignition is placed in the Off position. If ignition is placed in the Off position before obtaining the fault code, the vehicle may have to be driven in an effort to recreate the service condition.

If more than one service code is present, the first recognized flash out code can be obtained. If the yellow warning lamp is illuminated, but no fault codes are stored, a loss of power to the module, low brake fluid level or defective low brake fluid warning system may be present. In the case of low fluid level and defective brake fluid level warning system, the red brake system warning lamp may also be illuminated.


## Displaying and Reading Trouble Codes

**NOTE:** Ford DOES NOT provide procedures other than those described to retrieve trouble codes.

1. If ignition switch has been placed in Off position, start engine and operate vehicle in an effort to recreate the service condition.



**RABS Diagnostic Connector**



**Diagnostic Connector View**

2. Connect suitable jumper wire to the diagnostic connector (black/orange wire) then momentarily ground jumper wire to chassis. As ground connection is made and broken, the yellow warning lamp will begin to flash the fault code.
3. Fault codes will be displayed as short flashes and a long flash. As an example, two short flashes and one long flash would indicated flashout code 3. Observe flashout code several times to avoid misreading. The code will continue to flash until the ignition is placed in the Off position.
4. Refer to flashout code charts, and diagnostic charts, for diagnostic and testing procedures.
5. After correcting service condition, the vehicle may be operated to obtain the next flashout code as necessary.
6. After all flashout codes have been obtained and service conditions corrected, remove jumper wire from diagnostic connector.

TEST STEP		RESULT	ACTION TO TAKE
D2	NO FLASHOUT CODE BUT RABS LIGHT IS ILLUMINATED	No Flashout Code	GO to Test D2.
<ul style="list-style-type: none"> <li>● There are some faults that illuminate the REAR ANTILOCK light but will not provide a Flashout Code. Refer to Obtaining the Flashout Code in this Section for procedure. Also, be sure to make a good, momentary ground from the diagnostic lead.</li> </ul>			

**Fig. 64 Diagnostic Code**

TEST STEP		RESULT	ACTION TO TAKE
1a	NO TEST		
<ul style="list-style-type: none"> <li>This code should not occur. Refer to Obtaining the Flashout Code for procedures involved in getting the code.</li> </ul>		Flashout Code is 1	If after repeated attempts to take the Flashout Code, Code 1 is still obtained GO to Test E.

Fig. 65 Diagnostic Codes



TEST STEP		RESULT	ACTION TO TAKE
2a	<b>CHECK FOR OPEN RABS VALVE ISOLATION SOLENOID WIRING OR MODULE</b> <ol style="list-style-type: none"> <li>Turn ignition switch to the OFF position.</li> <li>Disconnect battery.</li> <li>Set the ohmmeter to the 200 ohm scale.</li> <li>Disconnect module harness connector from module.</li> <li>Check for resistance between harness connector Pin 13 and chassis ground.</li> </ol>  <p style="text-align: center;">MODULE HARNESS CONNECTOR-PIN VIEW</p>	Resistance less than 6 ohms  Resistance over 6 ohms	REPLACE RABS module.  GO to 2b.
2b	<b>CHECK FOR OPEN RABS VALVE ISOLATION SOLENOID OR WIRING</b> <ol style="list-style-type: none"> <li>Disconnect battery.</li> <li>Set ohmmeter to 200 ohm scale.</li> <li>Check resistance between valve connector isolation solenoid pin and connector ground pin.</li> </ol>  <p style="text-align: center;">RABS VALVE CONNECTOR -- PIN VIEW</p>	Resistance less than 6 ohms  Resistance over 6 ohms	REPAIR open in 500 circuit, isolation solenoid wire from valve to computer module. CHECK for dirty, loose or bent connector pins.  REPLACE RABS valve.

Fig. 67 Diagnostic Codes



TEST STEP		RESULT	ACTION TO TAKE
3a	<b>CHECK FOR OPEN RABS VALVE DUMP SOLENOID WIRING OR COMPUTER MODULE</b>		
	<ol style="list-style-type: none"> <li>Turn ignition switch to the off position.</li> <li>Disconnect the battery.</li> <li>Disconnect module harness connector from module.</li> <li>Place the ohmmeter on the 200 ohm scale.</li> <li>Check resistance between pin 8 (or pin 14) and chassis ground.</li> </ol>  <p>PIN NO. 14</p> <p>PIN NO. 8 MODULE HARNESS CONNECTOR --PIN VIEW</p>	Resistance less than 3 ohms  Resistance greater than 3 ohms	REPLACE computer module.  GO to Test 3b.
3b	<b>CHECK FOR OPEN RABS VALVE DUMP SOLENOID OR WIRING</b>		
	<ol style="list-style-type: none"> <li>Turn the ignition switch to the off position.</li> <li>Disconnect the battery.</li> <li>Disconnect RABS valve harness connector from valve connector.</li> <li>Check resistance between valve connector dump solenoid pin and ground pin.</li> </ol>  <p>DUMP SOLENOID PIN</p> <p>GROUND PIN</p> <p>RABS VALVE CONNECTOR -- PIN VIEW</p>	Resistance less than 3 ohms  Resistance greater than 3 ohms	REPAIR open in 664 circuit, dump solenoid wire, from valve to module. CHECK for loose, dirty or bent connector pins.  REPLACE RABS valve.

Fig. 69 Diagnostic Codes



TEST STEP		RESULT	ACTION TO TAKE
4a	<b>CHECK FOR CLOSED RABS VALVE SWITCH</b>		
	<ol style="list-style-type: none"> <li>Disconnect RABS valve harness connector from valve connector.</li> <li>Place ohmmeter on the 20K scale.</li> <li>Check resistance between valve connector switch pin and valve body.</li> </ol>  <p>SWITCH PIN</p> <p>RABS VALVE BODY GROUND</p> <p>RABS VALVE CONNECTOR -- PIN VIEW</p>	Resistance greater than 10K ohms  Resistance less than 10K ohms	GO to Test 4B.  REPLACE RABS valve.
4b	<b>CHECK RESISTANCE BETWEEN VALVE SWITCH AND VALVE GROUND</b>		
	<ol style="list-style-type: none"> <li>Set the ohmmeter on the 20K ohm scale.</li> <li>Check resistance between valve connector switch pin and valve solenoid ground pin.</li> </ol>  <p>VALVE SWITCH PIN</p> <p>GROUND PIN</p> <p>RABS VALVE CONNECTOR -- PIN VIEW</p>	Resistance 18-26K ohms  Resistance higher than 26K or lower than 18K	GO to Test 4C.  REPLACE RABS valve.

Fig. 71 iagnostic Codes


TEST STEP	RESULT	ACTION TO TAKE
<b>4c</b> CHECK FOR HYDRAULIC LEAK IN DUMP SECTION OF VALVE  1. Set the ohmmeter on the 200K scale. 2. Check resistance between valve connector switch pin and valve body with hydraulic pressure applied for at least 30 seconds.	Resistance greater than 10K ohms  Resistance lower than 10K ohms	GO to Test 4d.  REPLACE RABS valve.
 <p>SWITCH PIN</p> <p>RABS VALVE BODY GROUND.</p> <p>VALVE CONNECTOR -- PIN VIEW</p>		

Fig. 71 Diagnostic Codes



TEST STEP	RESULT	ACTION TO TAKE
<b>4d</b> CHECK FOR OPEN RABS VALVE GROUND WIRE  1. Set ohmmeter on 200 ohm scale. 2. Check for resistance between ground pin of harness connector and chassis ground.	Resistance less than 1 ohm  Resistance 1 ohm or more	GO to Test 4e.  REPAIR open in 397 circuit, isolation solenoid wire. CHECK for dirty or loose connector pins.
 <p>GROUND PIN</p> <p>RABS VALVE HARNESS CONNECTOR -- PIN VIEW</p>		
<b>4e</b> CHECK RESISTANCE IN RABS VALVE WIRING FROM THE MODULE CONNECTOR TO VALVE (OR MODULE)  1. Install RABS valve connector into valve. 2. Disconnect battery 3. Disconnect the module harness connector from the module. 4. Set the ohmmeter on 200K scale. 5. Check resistance between pin 4 and pin 6 of module harness connector.	Resistance 18-26K ohms  Resistance higher than 26K or lower than 18K	REPLACE computer module.  REPAIR open or short in 535 circuit, valve switch wire from valve to computer module.
 <p>SWITCH PIN NO. 6</p> <p>GROUND PIN NO. 4</p> <p>MODULE HARNESS CONNECTOR -- PIN VIEW</p>		

Fig. 71 Diagnostic Codes


TEST STEP		RESULT	ACTION TO TAKE
<b>5a</b>			
	For 4x2 vehicles or 4x4 vehicles for which the problem was initiated in 4x2 mode		GO to Step 5b.
	For 4x4 vehicles for which the problem was initiated in 4x4 mode only		GO to Step 5c.
<b>5b</b>	<b>CHECK FOR MECHANICAL PROBLEMS IN REAR BRAKE SYSTEM</b>		
	1. Disconnect the RABS module harness connector from the module to deactivate the RABS. 2. Drive the vehicle (in 4x2 mode). 3. Make normal stops in a safe area to determine the condition of the rear brake system.	Rear brakes are grabby or tend to lock up easily	REPAIR rear brake system and RETEST.
		Rear brakes are satisfactory for normal braking	REPLACE RABS valve.
<b>5c</b>	<b>CHECK FOR MISSING SIGNAL FROM 4 WD SWITCH TO COMPUTER MODULE</b>		
	1. Disconnect the RABS module harness from the module. 2. Turn ignition switch on. 3. Shift into 4x4 mode. 4. Set voltmeter to 20 VDC scale. 5. Measure voltage between pin 5 and chassis ground.	Voltage is less than 1 volt	REPLACE RABS valve.
		Voltage is greater than 1 volt	REPAIR 4x4 indicator switch.
	 <p>PIN NO. 5</p> <p>MODULE HARNESS CONNECTOR -PIN VIEW</p>		

Fig. 72 Diagnostic Codes



TEST STEP		RESULT	ACTION TO TAKE
<b>6a</b>	<b>CHECK FOR ERRATIC SENSOR SIGNAL AND LOOSE WIRE CONNECTIONS</b>		
<ol style="list-style-type: none"> <li>Turn ignition off.</li> <li>Disconnect battery.</li> <li>Set ohmmeter on the 2000 ohm scale.</li> <li>Check resistance between Pin 10 and Pin 3 of the harness connector while shaking the harness from sensor to module.</li> </ol>  <p>MODULE HARNESS CONNECTOR --PIN VIEW</p>		Constant reading of 1000 to 2000 ohms Reading is erratic	GO to Step 6b.  REPAIR loose connection in the 519 or 523 circuits (sensor leads). CHECK for dirty or loose pins, frayed or shorted connectors.
<b>6b</b>	<b>CHECK FOR METAL CHIPS ON SENSOR MAGNET POLE PIECE</b>		
<ul style="list-style-type: none"> <li>Remove the sensor from the differential and inspect for a build-up of metal chips on sensor magnetic pole.</li> </ul>		No metal chips are present  Metal chips are present	GO to Step 6c.  DRAIN and CLEAN differential. CHECK the excitor ring for broken or chipped teeth.
<b>6c</b>	<b>CHECK FOR EXCITOR RING DAMAGE</b>		
<ol style="list-style-type: none"> <li>Remove sensor from carrier.</li> <li>Rotate excitor ring and check for damage to teeth.</li> </ol>		Teeth are intact and no visible lateral runout is observed  Teeth are damaged or lateral runout of excitor ring is visible	REINSTALL sensor and GO to Test 6d.  REPAIR axle.
<b>6d</b>	<b>CHECK FOR ERRATIC OR LOW SENSOR OUTPUT ON COMPUTER MODULE</b>		
<ol style="list-style-type: none"> <li>Locate the sensor test connector.</li> <li>Position vehicle on a hoist and raise the rear wheels to clear the floor.</li> <li>Start the engine and turn the wheels at 5 mph.</li> <li>Place voltmeter on the 2000 mv AC scale.</li> <li>Measure voltage at the two pins of the sensor test connector.</li> </ol>  <p>SENSOR TEST CONNECTOR --PIN VIEW</p>		Voltage greater than 650 mV RMS and steady  Voltage less than 650 mV RMS or erratic	REPLACE module.  REPLACE sensor and recheck output and replace the sensor test connector cap.

Fig. 73 Diagnostic Codes



TEST STEP	RESULT	ACTION TO TAKE
<p><b>7a</b> CHECK FOR RABS VALVE ISOLATION SOLENOID OR WIRING SHORTED TO GROUND</p> <ol style="list-style-type: none"> <li>1. Turn ignition off.</li> <li>2. Disconnect the valve harness connector from the valve connector.</li> <li>3. Set the ohmmeter on the 200 ohm scale.</li> <li>4. Measure the resistance between the valve isolation solenoid pin and the valve ground pin in the valve connector.</li> </ol>  <p>RABS VALVE CONNECTOR -- PIN VIEW</p>	<p>Resistance is greater than 3 ohms</p> <p>Resistance is less than 3 ohms</p>	<p>GO to Test 7B.</p> <p>REPLACE RABS valve.</p>
<p><b>7b</b> CHECK FOR BLOWN INTERNAL FUSE IN THE MODULE</p> <ol style="list-style-type: none"> <li>1. Turn ignition off.</li> <li>2. Disconnect the battery.</li> <li>3. Disconnect the valve harness connector from the valve.</li> <li>4. Disconnect the module harness connector from the module.</li> <li>5. Place the ohmmeter on the 20K ohm scale.</li> <li>6. Measure the resistance between module harness connector pin 13 and chassis ground.</li> </ol>  <p>MODULE HARNESS CONNECTOR --PIN VIEW</p>	<p>Resistance greater than 20K ohms</p> <p>Resistance less than 20K ohms</p>	<p>REPLACE module.</p> <p>REPAIR short in 49.5 circuit between RABS valve and module. RECONNECT module and valve.</p>

Fig. 75 Diagnostic Codes



TEST STEP	RESULT	ACTION TO TAKE
<p><b>Ba</b> CHECK FOR RABS VALVE SOLENOID OR WIRING SHORTED TO GROUND</p> <ol style="list-style-type: none"> <li>1. Turn Ignition switch off.</li> <li>2. Disconnect valve harness connector from valve connector.</li> <li>3. Set the ohmmeter on the 200 ohm scale.</li> <li>4. Measure the resistance between the valve dump solenoid pin and the valve ground pin in the valve connector.</li> </ol>  <p>RABS VALVE CONNECTOR -- PIN VIEW</p>	<p>Resistance greater than 1 ohm</p> <p>Resistance is less than 1 ohm</p>	<p>GO to Test Bb.</p> <p>REPLACE RABS valve.</p>
<p><b>Bb</b> CHECK COMPUTER MODULE</p> <ol style="list-style-type: none"> <li>1. Turn ignition off.</li> <li>2. Disconnect battery.</li> <li>3. Disconnect valve harness connector from valve connector.</li> <li>4. Disconnect the module harness connector from the module.</li> <li>5. Set the ohmmeter on the 20K ohm scale.</li> <li>6. Measure the resistance between module harness connector pin 8 (or pin 14) and chassis ground.</li> </ol>  <p>MODULE HARNESS CONNECTOR -- PIN VIEW</p>	<p>Resistance greater than 20K ohm</p> <p>Resistance less than 20K ohm</p>	<p>REPLACE module.</p> <p>REPAIR short in 684 circuit between RABS valve and RABS module. RECONNECT module and valve.</p>

Fig. 77 Diagnostic Codes



TEST STEP	RESULT	ACTION TO TAKE
<p><b>9a</b> CHECK FOR OPEN SENSOR OR SENSOR WIRING</p> <ol style="list-style-type: none"> <li>1. Turn key off.</li> <li>2. Disconnect sensor harness connector from the sensor on the differential.</li> <li>3. Set the ohmmeter on the 20K ohm scale.</li> <li>4. Measure the resistance at the two sensor pins.</li> </ol>  <p style="text-align: center;">SENSOR -- PIN VIEW</p>	<p>Resistance less than 2500 ohms</p> <p>Resistance greater than 2500 ohms</p>	<p>GO to Test 9b.</p> <p>REPLACE sensor.</p>
<p><b>9b</b> CHECK FOR OPEN SENSOR HARNESS WIRING</p> <ol style="list-style-type: none"> <li>1. Turn key off.</li> <li>2. Disconnect battery.</li> <li>3. Reconnect sensor harness connector to sensor.</li> <li>4. Disconnect module harness connector from module.</li> <li>5. Set the ohmmeter on the 20K ohm scale.</li> <li>6. Measure the resistance between harness connector pins 3 and 10.</li> </ol>  <p style="text-align: center;">MODULE HARNESS CONNECTOR -- PIN VIEW</p>	<p>Resistance less than 2500 ohms</p> <p>Resistance greater than 2500 ohms</p>	<p>REPLACE module.</p> <p>REPAIR open in circuits 519 or 523, sensor wires between the sensor and module. CHECK for loose or dirty pin connectors. If defect is found in 14A107 — Jumper Harness (from sensor to left frame rail), REPLACE with original equipment high flex wire.</p>

Fig. 78 Diagnostic Codes




TEST STEP	RESULT	ACTION TO TAKE
<p><b>10a</b> CHECK FOR SHORTED SENSOR</p> <ol style="list-style-type: none"> <li>Turn ignition off.</li> <li>Disconnect the sensor harness from the sensor.</li> <li>Place the ohmmeter on the 20K ohms scale.</li> <li>Measure the resistance at the two sensor pins.</li> </ol> 	<p>Resistance less than 1000 ohms</p> <p>Resistance is greater than 1000 ohms</p>	<p>REPLACE sensor.</p> <p>GO to Test 10b.</p>
<p><b>10b</b> CHECKING FOR GROUNDED SENSOR WIRING</p> <ol style="list-style-type: none"> <li>Turn ignition off.</li> <li>Disconnect the battery.</li> <li>Disconnect the sensor harness connector from the sensor.</li> <li>Disconnect the module harness connector from the module.</li> <li>Set the ohmmeter on the 20K ohm scale.</li> <li>Measure the resistance from pin 10 of the harness connector to chassis ground.</li> </ol> 	<p>Resistance less than 20K ohms</p> <p>Resistance is greater than 20K ohms</p>	<p>REPAIR short to ground in 523 circuit, sensor HI lead to module. CHECK for frayed wires or shorted connectors. If defect is found in the 14A107 Jumper Harness (from sensor to left frame rail), REPLACE with original equipment high flex wire.</p> <p>GO to Test 10c.</p>
<p><b>10c</b> CHECK FOR SHORTED SENSOR WIRING</p> <ol style="list-style-type: none"> <li>Turn ignition off.</li> <li>Disconnect sensor harness connector from the sensor.</li> <li>Disconnect the module harness connector from the module.</li> <li>Place the ohmmeter on the 20K ohms scale.</li> <li>Measure the resistance from pin 3 to pin 10 of the harness connector.</li> </ol> 	<p>Resistance less than 20K ohms</p> <p>Resistance greater than 20K ohms</p>	<p>REPAIR short between the 523 and 519 sensor circuits. CHECK for frayed wires or shorted connectors. If defect is found in the 14A107 Jumper Harness (from sensor to left frame rail), REPLACE with original equipment high flex wire.</p> <p>REPLACE the RABS module.</p>

Fig. 79 Diagnostic Codes

TEST STEP		RESULT	ACTION TO TAKE
<b>11a</b>	<b>CHECK VEHICLE STOP LIGHTS</b>		
<ul style="list-style-type: none"> <li>Apply the service brakes and observe the rear brake lamps.</li> </ul>		Lamps illuminate Lamps do not illuminate	GO to Test 11b.  REPAIR or REPLACE vehicle stop light switch. CHECK for blown stop light switch fuse. Investigate reason for blown fuse. CHECK for open stop light switch wiring or blown stop lamps. REPAIR as needed.
<b>11b</b>	<b>WIRING FROM MODULE TO BRAKE SWITCH</b>		
<ul style="list-style-type: none"> <li>Check for an open between the brake switch and the module:                             <ol style="list-style-type: none"> <li>Turn the ignition off.</li> <li>Set the voltmeter on the 20 VDC scale.</li> <li>Remove the module harness connector</li> <li>Measure the voltage between pin 11 and chassis ground while stepping on the brake pedal.</li> </ol> </li> </ul>		Voltage is less than 9V  Voltage is 9V or more	REPAIR the open in the 511 circuit.  CHECK 4 way flasher and directional wiring. This condition could create feedback through the stop light circuit. Also, cruise controls may not operate correctly.




Fig. 80 Diagnostic Codes

TEST STEP		RESULT	ACTION TO TAKE
<b>12a</b>			
<ul style="list-style-type: none"> <li>Check the brake fluid level at the master cylinder reservoir.</li> </ul>		Brake fluid level low  Brake fluid level OK	Check for fluid leaks in vehicle brake system and repair as required. Fill master cylinder to required level.  REPLACE module.

Fig. 83 Diagnostic Codes

TEST STEP		RESULT	ACTION TO TAKE
<b>13a</b>	<b>NO TEST</b>		
<ul style="list-style-type: none"> <li>RABS module speed circuit phase lock loop failure detected during module self test.</li> </ul>		13 flashes are present	REPLACE RABS module.

Fig. 85 Diagnostic Codes

TEST STEP		RESULT	ACTION TO TAKE
14a	NO TEST		
<ul style="list-style-type: none"> <li>• RABS module program check sum failure detected during self test.</li> </ul>		If 14 flashes are present	REPLACE RABS module.

Fig. 87 Diagnostic Codes

TEST STEP		RESULT	ACTION TO TAKE
15a	NO TEST		
<ul style="list-style-type: none"> <li>• RABS module RAM failure detected during self test.</li> </ul>		If 15 flashes are present	REPLACE RABS module.

Fig. 89 Diagnostic Codes

TEST STEP		RESULT	ACTION TO TAKE
16a	NO TEST		
<ul style="list-style-type: none"> <li>• This code should not occur. Refer to obtaining the Flashout Code for procedures involved in getting the code.</li> </ul>		Flashout Code is 16	If after repeated attempts to take the Flashout Code, Code 16 is still obtained, REPLACE RABS module.

Fig. 91 Diagnostic Codes

## Brake System (Red) Warning Lamp

To check brake system warning lamp, turn ignition key to the Start position. The red warning lamp should glow momentarily. The warning lamp will also illuminate if the parking brake mechanism is not fully released. If warning lamp fails to glow, service of the electrical system is indicated. If warning lamp illuminates with ignition key in the Run position, check and repair conventional brake system as required. If conventional brake system is found to be operating properly, check anti-lock brake system for stored codes as outlined under **ACCESSING FLASHOUT CODES AND CODE DESCRIPTION**. In certain instances both red and yellow warning lamps will glow simultaneously. If this occurs, check and repair conventional brake system as required. If red warning lamp continues to glow, refer to **WARNING LAMP CONDITION CHART** for proper diagnostic and testing procedures, then refer to **Brakes and Traction Control/Brakes/Antilock Brake System/Testing and Inspection/Procedures/Pinpoint Test Charts** Tests A through G, as required.

## Antilock Brake System (Yellow) Warning Lamp

To check anti-lock brake system warning lamp, turn ignition key to the On position. The yellow warning lamp should glow for approximately two seconds and then shut off. If warning lamp fails to glow, or glows continuously, refer to **WARNING LAMP CONDITION CHART** for proper diagnostic and testing procedures, then refer to **Brakes and Traction Control/Brakes/Antilock Brake System/Testing and Inspection/Procedures/Pinpoint Test Charts** Tests A through G, as required. In addition, if warning lamp continues to glow during vehicle operation, check anti-lock brake system for stored codes as outlined under **ACCESSING FLASHOUT CODES AND CODE DESCRIPTION**.



TEST STEP	RESULT	ACTION TO TAKE
<b>A1</b>   <b>MODULE HARNESS CONNECTOR</b>		
<ul style="list-style-type: none"> <li>Check to make sure module harness is fully plugged into computer module.</li> </ul>	Harness is fully plugged in Harness is not fully plugged in	GO to Test A2. CONNECT harness to module.
<b>A2</b>   <b>COMPUTER MODULE GROUND</b>		
<ul style="list-style-type: none"> <li>Check for good computer module ground:                             <ol style="list-style-type: none"> <li>Disconnect Battery</li> <li>Remove harness connector from module.</li> <li>Set ohmmeter on the 200 ohm scale.</li> <li>Check for resistance between harness connector pin 4 and chassis ground</li> </ol> </li> </ul>  <p>MODULE HARNESS CONNECTOR — PIN VIEW</p> <p><b>CAUTION: WHEN CHECKING RESISTANCE IN THE ANTILOCK SYSTEM, ALWAYS DISCONNECT THE BATTERY. IMPROPER RESISTANCE MAY OCCUR WITH THE VEHICLE BATTERY CONNECTED.</b></p>	Resistance less than 1 ohm Resistance 1 ohm or greater	GO to Test A3. CHECK for open in module ground wire. CHECK for loose, dirty or broken connector pins.
<b>A3</b>   <b>ANTILOCK LIGHT POWER</b>		
<ul style="list-style-type: none"> <li>Check for voltage to ANTILOCK light:                             <ol style="list-style-type: none"> <li>Reconnect the battery.</li> <li>Set voltmeter on 20 VDC scale position.</li> <li>Turn ignition to the on position.</li> <li>Check voltage between harness connector pin 7 and a known good chassis ground.</li> </ol> </li> </ul>  <p>MODULE HARNESS CONNECTOR — PIN VIEW</p>	Voltage greater than 9V Voltage less than 9V	REPLACE Module. GO to Test A4

Fig. 34 Test Chart A

TEST STEP	RESULT	ACTION TO TAKE
<b>A4</b>   <b>RABS 15 AMP LIGHT FUSE</b>		
<ul style="list-style-type: none"> <li>Remove and inspect RABS 15 amp light fuse.</li> </ul>	Fuse is OK Fuse is blown	REPLACE fuse and GO to Test A5. CHECK for short to ground between fuse panel and warning lamps. REPAIR short and replace 15 amp fuse.
<b>A5</b>   <b>POWER TO RABS LIGHT FUSE</b>		
<ul style="list-style-type: none"> <li>Check for voltage to fuse.                             <ol style="list-style-type: none"> <li>Set voltmeter to 20 VDC scale.</li> <li>Turn ignition to the on position.</li> <li>Check voltage between panel fuse connector and known good chassis ground.</li> </ol> </li> </ul>	Voltage greater than 9V Voltage less than 9V	GO to Test A6. REPAIR fuse panel or vehicle electrical system.
<b>A6</b>   <b>RABS LIGHT BULB</b>		
<ul style="list-style-type: none"> <li>Check RABS light bulb.</li> </ul>	Bulb is OK Bulb is not OK	REPAIR open between RABS light fuse and pin 7 of the module wiring harness connector. REPLACE bulb.

Fig. 34 Test Chart A

TEST STEP		RESULT	ACTION TO TAKE
<b>B1</b>	<b>PARKING BRAKE</b>		
<ul style="list-style-type: none"> <li>Check parking brake application:               <ol style="list-style-type: none"> <li>Turn ignition key to the on position.</li> <li>Check the parking brake pedal and release if applied.</li> </ol> </li> </ul>		BRAKE light goes off	PERFORM road test. If lockup occurs GO to Test B2.
		BRAKE light stays on	GO to Test B2.
<b>B2</b>	<b>PARKING BRAKE SWITCH</b>		
<ul style="list-style-type: none"> <li>Check parking brake switch:               <ol style="list-style-type: none"> <li>Disconnect the parking brake switch connector.</li> </ol> </li> </ul>		BRAKE light goes off	ADJUST parking brake or REPLACE parking brake switch.
		BRAKE light remains on	GO to Test B3.
<b>B3</b>	<b>MODULE AND WIRING</b>		
<ul style="list-style-type: none"> <li>Remove module harness connector from module.</li> </ul>		BRAKE light goes off	REPLACE the computer module.
		If BRAKE light remains on	CHECK for short to ground in wiring from BRAKE light to the RABS diode resistor

Fig. 36 Test Chart B

TEST STEP		RESULT	ACTION TO TAKE
<b>C1</b>	<b>LOW BRAKE FLUID</b>		
<ul style="list-style-type: none"> <li>Check the brake fluid level at the master cylinder reservoir.</li> </ul>		Brake fluid level OK	GO to Test C2.
		Brake fluid level low	CHECK for fluid leaks in vehicle brake system and repair as required. Fill master cylinder to required level.
<b>C2</b>	<b>MASTER CYLINDER FLOAT</b>		
<ul style="list-style-type: none"> <li>Check master cylinder float for buoyancy:               <ol style="list-style-type: none"> <li>Remove cap from master cylinder reservoir.</li> <li>Using a clean steel implement, push down on float in reservoir.</li> </ol> </li> </ul>		Float moves down	GO to Test C3.
		Float does not move down (sits at the bottom of the reservoir)	REPLACE master cylinder reservoir.
<b>C3</b>	<b>DIODE/RESISTOR ELEMENT</b>		
<ul style="list-style-type: none"> <li>Check for proper functioning of the diode/resistor element.               <ol style="list-style-type: none"> <li>Turn ignition key to the on position.</li> <li>Check parking brake and release if applied.</li> </ol> </li> </ul>		Both the ANTILOCK and BRAKE warning lamps go off	REPLACE RABS diode/resistor element.
		Both the ANTILOCK and BRAKE warning lamps stay on	GO to Test C4.
<b>C4</b>	<b>DIODE/RESISTOR ELEMENT CONTINUED</b>		
<ul style="list-style-type: none"> <li>Continue to check for proper functioning of the diode/resistor element.               <ol style="list-style-type: none"> <li>Remove the parking brake switch and the diesel low vacuum switch, if so equipped.</li> </ol> </li> </ul>		Both the ANTILOCK and BRAKE warning lamps go off	REPLACE RABS diode/resistor element.
		Both the ANTILOCK and BRAKE warning lamps stay on	GO to Test C5.

Fig. 37 Test Chart C

TEST STEP		RESULT	ACTION TO TAKE
<b>C5</b>	<b>ANTILOCK VALVE SWITCH</b>		
<ul style="list-style-type: none"> <li>Obtain the flashout code as described in Diagnostics and Testing</li> </ul>		Flashout code is obtained	REFER to Flashout Codes Charts
		ANTILOCK and BRAKE warning lamps stay on steady	GO to Test C6.
<b>C6</b>	<b>MASTER CYLINDER SWITCH</b>		
<ul style="list-style-type: none"> <li>Check for proper functioning of the master cylinder fluid level indicator switch:               <ol style="list-style-type: none"> <li>Remove the connector from the master cylinder.</li> <li>Connect a jumper wire between the two purple/white wires in the connector.</li> <li>Turn the ignition key to the on position.</li> </ol> </li> </ul>		ANTILOCK and BRAKE warning lamps stay on	GO to Test C7.
		ANTILOCK and BRAKE warning lamps go off	REPLACE the master cylinder reservoir.
<b>C7</b>	<b>BRAKE LIGHT WIRING</b>		
<ul style="list-style-type: none"> <li>Check for shorts in brake light wiring.               <ol style="list-style-type: none"> <li>Disconnect module harness connector from module.</li> <li>Turn ignition key to the on position.</li> </ol> </li> </ul>		ANTILOCK light goes off and BRAKE light stays on	CHECK for short to ground in the 977 circuit. REFER to wiring diagram
		Both ANTILOCK and BRAKE warning lamps go off	REPLACE module.

Fig. 37 Test Chart C


TEST STEP		RESULT	ACTION TO TAKE
<b>D1</b>	<b>OBTAIN THE FLASHOUT CODE</b>		
<ul style="list-style-type: none"> <li>Obtain the flashout code as described in Diagnostics and Testing</li> </ul>  <p>RABS DIAGNOSTIC CONNECTOR -- PIN VIEW</p>		Flashout code cannot be obtained Flashout code is obtained	GO to Test D2. Refer to the Flashout Code Charts
<b>D2</b>	<b>MASTER CYLINDER CONNECTOR</b>		
<ul style="list-style-type: none"> <li>Make sure master cylinder connector is fully plugged in.</li> </ul>		Master cylinder connector is not fully plugged in Master cylinder connector is plugged in	PLUG in the master cylinder connector. GO to Test D2A.
<b>D2A</b>	<b>M/C PRESS. DIFFERENTIAL CONNECTOR</b>		
<ul style="list-style-type: none"> <li>Make sure master cylinder pressure differential connector is fully plugged in (Aerostar only).</li> </ul>		Pressure differential switch connector is not fully plugged in Pressure differential switch connector is plugged in	PLUG in the master cylinder pressure differential switch connector. GO to Test D3.
<b>D3</b>	<b>RABS 20 AMP FUSE</b>		
<ul style="list-style-type: none"> <li>Remove and inspect the RABS 20 amp fuse.</li> </ul>		Fuse is OK Fuse is blown	REPLACE Fuse. GO to Test D4. Short to ground between the fuse panel and the module wiring harness connector. REPAIR short in the 601 or 601A circuit and REPLACE the 20 amp. fuse. REFER to the Wiring Diagrams

Fig. 39 Test Chart D



TEST STEP	RESULT	ACTION TO TAKE
<p><b>D4 SHORTS IN MODULE HARNESS CONNECTOR WIRING</b></p> <ul style="list-style-type: none"> <li>Check wiring for short to ground:               <ol style="list-style-type: none"> <li>Turn ignition switch to the on position.</li> <li>Remove the module harness connector from the module.</li> <li>Observe the REAR ANTILOCK light.</li> </ol> </li> </ul>	<p>Light goes off</p> <p>Light remains on</p>	<p>GO to Test D5.</p> <p>CHECK for a short to ground in the 603 Circuit. REFER to Wiring Diagram</p>
<p><b>D5 POWER TO THE MODULE</b></p> <ul style="list-style-type: none"> <li>Check for an open in the circuit supplying power to the module:               <ol style="list-style-type: none"> <li>Set the voltmeter on the 20 VDC scale.</li> <li>Turn the ignition switch to the on position.</li> <li>Measure the voltage between pin 1 (or pin 9) and chassis ground.</li> </ol> </li> </ul>  <p>MODULE HARNESS CONNECTOR - PIN VIEW</p>	<p>Voltage less than 9V.</p> <p>Voltage greater than 9V.</p>	<p>REPAIR the open in the 601 or 601A circuit or power to the fuse panel. See Wiring Diagram.</p> <p>GO to Test D6.</p>
<p><b>D6 VOLTAGE AT THE FLUID LEVEL CIRCUIT</b></p> <ul style="list-style-type: none"> <li>Check the voltage from the fluid level switch circuit:               <ol style="list-style-type: none"> <li>Set the voltmeter on the 20 VDC Scale.</li> <li>Turn the ignition switch to the on position.</li> <li>Measure the voltage between pin 2 and chassis ground.</li> </ol> </li> </ul>  <p>MODULE HARNESS CONNECTOR - PIN VIEW</p>	<p>Voltage less than 8V.</p> <p>Voltage greater than 8V.</p>	<p>GO to Test D7.</p> <p>GO to Test D8.</p>

Fig. 39 Test Chart D



TEST STEP	RESULT	ACTION TO TAKE
<p><b>D7</b> FLUID LEVEL SENSOR AND WIRING</p> <ul style="list-style-type: none"> <li>Check for voltage at the fluid level sensor:               <ol style="list-style-type: none"> <li>Set voltmeter on the 20 VDC scale.</li> <li>Turn the ignition switch to the on position.</li> <li>Measure the voltage at the purple/white wire (No. 977), and at the purple/yellow wire (No. 128) at the back of the master cylinder fluid level switch connector without disconnecting the connector.</li> </ol> </li> </ul> <p>BLACK WIRE (NO. 97)            PURPLE/YELLOW WIRE (NO. 128)            (RANGER/EXPLORER)            PURPLE/WHITE WIRE (NO. 977A)            (AEROSTAR)            PURPLE/WHITE WIRE (NO. 977)            MASTER CYLINDER            FLUID LEVEL SWITCH            CONNECTOR</p> 	<p>Voltage greater than 8V at both wires.</p> <p>Voltage less than 8V at both wires.</p> <p>Voltage greater than 8V at one wire and less than 8V at the other wire.</p>	<p>CHECK for open in 128 (Ranger) or 977A (Aerostar) and 977 circuits.</p> <p>REPLACE diode resistor element or open in 640 circuit.</p> <p>CHANGE the master cylinder reservoir.</p>
<p><b>D8</b> GROUNDED DIAGNOSTIC LEAD</p> <ul style="list-style-type: none"> <li>Check the voltage at the diagnostic lead.               <ol style="list-style-type: none"> <li>Reconnect the module harness connector.</li> <li>Set the voltmeter on the 20 VDC scale.</li> <li>Turn the ignition to the on position.</li> <li>Measure the voltage between the diagnostic lead and chassis ground.</li> </ol> </li> </ul>  <p>RABS DIAGNOSTIC            CONNECTOR            PIN VIEW</p>	<p>Voltage is less than 1V</p> <p>Voltage is greater than 1V</p>	<p>CHECK for a short in the 571 diagnostic circuit. If no short is found, GO to Test D9.</p> <p>GO to Test D9.</p>
<p><b>D9</b> COMPUTER MODULE</p> <ul style="list-style-type: none"> <li>Replace computer module and retest.</li> </ul>		

Fig. 39 Test Chart D




TEST STEP	RESULT	ACTION TO TAKE
<p><b>E1</b> <b>INTERMITTENT POWER TO MODULE</b></p> <ul style="list-style-type: none"> <li>Check for intermittent open in the 601 and 601A circuit, power to module               <ol style="list-style-type: none"> <li>Remove the module harness connector from the module.</li> <li>Set the voltmeter on the 20 VDC scale.</li> <li>Turn the ignition to ON position.</li> <li>Shake the instrument panel harness. Check for battery voltage between pin 1 (and pin 9) and chassis ground.</li> </ol> </li> </ul>  <p style="text-align: center;">MODULE HARNESS CONNECTOR -PIN VIEW</p>	<p>Voltage is steady and greater than 9V</p> <p>Voltage is intermittent or less than 9V</p>	<p>GO to Test <b>E2</b></p> <p>REPAIR break in the 601 and 601A circuit REFER to Wiring Diagram</p>
<p><b>E2</b> <b>GROUNDING DIAGNOSTIC LEAD</b></p> <ul style="list-style-type: none"> <li>Check for an intermittent ground to chassis in the diagnostic lead circuit:               <ol style="list-style-type: none"> <li>Turn the ignition switch off.</li> <li>Disconnect the battery.</li> <li>Set the ohmmeter on the 200K ohm scale</li> <li>Shake the module harness and check the resistance between pin 12 and chassis ground.</li> </ol> </li> </ul>  <p style="text-align: center;">MODULE HARNESS CONNECTOR -PIN VIEW</p>	<p>Resistance is steady and greater than 100K ohms</p> <p>Resistance is below 100K ohms or fluctuates</p>	<p>GO to Test <b>E3</b></p> <p>REPAIR short in the 571 circuit. REFER to Wiring Diagram</p>
<p><b>E3</b> <b>FAULTY MODULE GROUND</b></p> <ul style="list-style-type: none"> <li>Check for intermittent or poor module ground               <ol style="list-style-type: none"> <li>Disconnect the battery.</li> <li>Set the voltmeter on the 200 ohm scale</li> <li>Shake the module harness and check the resistance between pin 4 of the module harness connector and chassis ground.</li> </ol> </li> </ul>  <p style="text-align: center;">MODULE HARNESS CONNECTOR -PIN VIEW</p>	<p>Resistance is less than 1 ohm and steady</p> <p>Resistance is greater than 1 ohm or fluctuates</p>	<p>REPLACE module.</p> <p>REPAIR poor ground in the 570 circuit. REFER to Wiring Diagrams</p>

Fig. 41 Test Chart E


TEST STEP		RESULT	ACTION TO TAKE
<b>F1</b>	<b>STOPLAMPS</b>		
<ul style="list-style-type: none"> <li>Check for stoplamp operation:                             <ol style="list-style-type: none"> <li>Apply the service brakes and observe the rear brakelamps.</li> </ol> </li> </ul>		Rear stoplamps not illuminated Rear stoplamps OK	REPAIR the stoplamp circuit. GO to Test F2.
<b>F2</b>	<b>VEHICLE ROAD TEST</b>		
<ul style="list-style-type: none"> <li>Perform a low speed vehicle road test:                             <ol style="list-style-type: none"> <li>At approximately 10 mph apply the service brakes in an attempt to lock all four wheels while observing the left rear wheel in the side mirror.</li> </ol> </li> </ul>		Rear wheels lock Rear wheels do not lock	GO to Test F3. The system is now functioning OK. Consider a possible intermittent wiring problem or possibly a problem which only shows up during driving. REFER to Flashout Code 6
<b>F3</b>	<b>WIRING FROM MODULE TO BRAKE SWITCH</b>		
<ul style="list-style-type: none"> <li>Check for an open between the brake switch and the module:                             <ol style="list-style-type: none"> <li>Turn the ignition off.</li> <li>Set the voltmeter on the 20 VDC scale.</li> <li>Remove the module harness connector.</li> <li>Measure the voltage between pin 11 and chassis ground while stepping on the brake pedal.</li> </ol> </li> </ul>		Voltage is less than 9V Voltage is 9V or more	REPAIR the open in the 511 circuit. GO to Test F4.
 <p style="text-align: center;">PIN NO. 11</p> <p style="text-align: center;">MODULE HARNESS CONNECTOR -- PIN VIEW</p>			
<b>F4</b>	<b>EXCITOR RING INSPECTION</b>		
<ul style="list-style-type: none"> <li>Remove sensor from carrier and check for:                             <ol style="list-style-type: none"> <li>Presence of the excitor ring</li> <li>Condition of the teeth.</li> </ol> </li> </ul>		Ring is present with the teeth intact Ring is not present or the teeth are damaged	REINSTALL the sensor and GO to Test F5. REPAIR axle.

Fig. 42 Test Chart F


TEST STEP		RESULT	ACTION TO TAKE
<b>F5</b>	<b>SENSOR OUTPUT</b>		
<ul style="list-style-type: none"> <li>Check for low sensor signal output:                             <ol style="list-style-type: none"> <li>Set the voltmeter on the 2000 mV AC scale.</li> <li>Position the vehicle on the hoist and raise the rear wheels off the ground.</li> <li>Remove the cap from the sensor test connector and connect the voltmeter across the connector leads.</li> <li>Start the engine and turn the rear wheels at 5 mph.</li> <li>Measure the voltage output of the sensor.</li> </ol> </li> </ul>		Voltage is 850 mV (RMS) or greater	REINSTALL the sensor test connector cap and GO to Test F7.
		Voltage is less than 650 mV (RMS)	REPLACE the sensor, RETEST, and REINSTALL the sensor test connector cap.  If the voltage is still low, GO to Test F6.
			
<b>F6</b>	<b>SENSOR GAP</b>		
<ul style="list-style-type: none"> <li>Determine the sensor gap:                             <ol style="list-style-type: none"> <li>Remove the sensor from the carrier.</li> <li>Measure the height of the sensor pole piece from the mounting face of the sensor flange. Pole should be 1.07-1.08 inch.</li> <li>Measure the depth to the top of the excitor ring teeth from the sensor mounting face on the carrier.</li> <li>Subtract the two measurements. This is the sensor gap.</li> </ol> </li> </ul>		Gap is less than 0.050 inches	GO to Test F7.
		Gap is greater than 0.050 inches	The gap is too large. CHECK for defective sensor or carrier housing.
<b>F7</b>	<b>MECHANICAL PROBLEMS IN REAR BRAKES</b>		
<ul style="list-style-type: none"> <li>Check the rear brakes for mechanical problems such as grabbing, locking or pulling.</li> </ul>		Rear Brakes OK	GO to Test F8.
		Rear brakes lock, grab or pull	REPAIR and RETEST.
<b>F8</b>	<b>COMPUTER MODULE</b>		
<ul style="list-style-type: none"> <li>Replace computer module and retest.</li> </ul>			

Fig. 42 Test Chart F

TEST STEP		RESULT	ACTION TO TAKE
<b>G1</b>	<b>MASTER CYLINDER CONNECTORS</b>		
<ul style="list-style-type: none"> <li>Check connectors on master cylinder, brake fluid level switch and delta pressure switch if equipped.</li> </ul>		Connectors are fully plugged in	GO to Test G2.
		Connector is not fully plugged in	CONNECT connector to master cylinder.
<b>G2</b>	<b>RED BRAKE WARNING LIGHT</b>		
<ul style="list-style-type: none"> <li>Apply parking brake to see if red brake warning light lights.</li> </ul>		Red warning light lights	GO to Test D6.
		Red warning light does not light	REPAIR warning lamp circuit. CHECK for open bulb.

Fig. 43 Test Chart G

### Chart Description

Test Step Description

- A1 - Module Harness Connector
- A2 - Computer Module Ground
- A3 - Antilock Light Power
- A4 - RABS 15 Amp Light Fuse
- A5 - Power to RABS Light Fuse

A6 - RABS Light Bulb

B1 - Parking Brake

B2 - Parking Brake Switch

B3 - Module and Wiring

C1 - Low Brake Fluid

C2 - Master Cylinder Float

C3 - Diode/Resistor Element

C4 - Diode/Resistor Element (Continued)

C5 - Antilock Valve Switch

C6 - Master Cylinder Switch

C7 - Brake Light Wiring

D1 - Obtain the Flashout Code

D2 - Master Cylinder Connector

D2A - M/C Press. Differential Connector

D3 - RABS 20 Amp Fuse

D4 - Shorts in Module Harness Connector Wiring

D5 - Power to the Module

D6 - Voltage at the Fluid Level Circuit

D7 - Fluid Level Sensor and Wiring

D8 - Grounded Diagnostic Lead

D9 - Computer Module

E1 - Intermittent Power to Module

E2 - Grounded Diagnostic Lead

E3 - Faulty Module Ground

F1 - Stoplamps

F2 - Vehicle Road Test

F3 - Wiring from Module to Brake Switch

F4 - Excitor Ring Inspection

F5 - Sensor Output

F6 - Sensor Gap

F7 - Mechanical Problems in Rear Brakes

F8 - Computer Module

G1 - Master Cylinder Connectors

G2 - Red Brake Warning Light

Condition	Action to Take
Yellow ANTILOCK Light Off and Does Not Self-Check	See Test <b>A</b>
Yellow ANTILOCK Light Off, and ANTILOCK Light Does Self-Check, Red BRAKE Light On	See Test <b>B</b>
Yellow ANTILOCK Light On and Red BRAKE Light On	See Test <b>C</b>
Yellow ANTILOCK Light On, Red BRAKE Light Off	See Test <b>D</b>
Yellow ANTILOCK Light Flashing, Red BRAKE Light Off	See Test <b>E</b>
Rear Wheels Lock with Hard Stops -- Both Lamps Functioning Properly (Light Self-Checks are OK and Lights are OFF)	See Test <b>F</b>
Yellow ANTILOCK Light Self-Checks, Red Brake Light Does Not Self Check	See Test <b>G</b>
Flashout Code is Known	See Flashout Codes Chart

**CAUTION: WHEN CHECKING RESISTANCE IN THE ANTILOCK BRAKE SYSTEM, ALWAYS DISCONNECT THE BATTERY. IMPROPER RESISTANCE READINGS WILL OCCUR WITH THE VEHICLE BATTERY CONNECTED.**

Fig. 27 Warning Lamp Condition Chart