

Vehicle: Diagrams**Splices**

Splice	Location
S100	Transmission control harness, near Take Out (T/O) to C115
S102	Transmission control harness, near T/O to C114
S103	Fuel charge harness, near T/O to C117
S104	Fuel charge harness, near T/O to C120
S105	Fuel charge harness, near T/O to C123
S106	Fuel charge harness, near T/O to C122
S107	Fuel charge harness, near T/O to C134
S108	Engine control harness, near T/O to engine compartment fuse panel
S109	Engine control harness, near T/O to engine compartment fuse panel
S110	Engine control harness, near T/O to engine compartment fuse panel
S111	Engine control harness, near T/O to engine compartment fuse panel
S112	Engine control harness, near T/O to engine compartment fuse panel
S113	Engine control harness, near T/O to engine compartment fuse panel
S114	Engine control harness, near T/O to engine compartment fuse panel
S115	Engine control harness, near T/O to engine compartment fuse panel
S116	Engine control harness, near T/O to engine compartment fuse panel
S117	Engine control harness, near T/O to C100
S118	Engine control harness, near T/O to C100
S119	Engine control harness, near T/O to C100
S120	Engine control harness, near T/O to C234
S121	Engine control harness, near T/O to C229
S122	Engine control harness, near T/O to C229
S124	Engine control harness, near T/O to C229
S126	Engine control harness, near T/O to C234
S127	Engine control harness, near T/O to C147
S128	Engine control harness, near T/O to C147
S129	Engine control harness, near T/O to C234
S130	Engine control harness, in T/O to C234
S131	Engine control harness, near T/O to C234
S132	Engine control harness, near T/O to C150
S133	Engine control harness, near T/O to C152
S134	Engine control harness, near T/O to C152
S135	Engine control harness, near T/O to C152
S136	Engine control harness, near T/O to C152
S137	Engine control harness, in T/O to C154
S138	Engine control harness, near T/O to C152
S139	Engine control harness, near T/O to C152
S140	Engine control harness, near T/O to C152
S141	Engine control harness, near T/O to C155
S142	Engine control harness, near T/O to C155
S143	Engine control harness, near T/O to C159
S144	Engine control harness, near T/O to C159
S145	Engine control harness, near T/O to C229
S146	Engine control harness, near T/O to C229
S147	Engine control harness, near T/O to C152
S148	Engine control harness, near T/O to C121
S149	Engine control harness, near T/O to C123
S150	Engine control harness, near T/O to C122
S151	Engine control harness, near T/O to C136
S152	Engine control harness, near T/O to C171
S153	Engine control harness, near T/O to C129
S154	Engine control harness, near T/O to C170
S155	Engine control harness, near T/O to C134
S156	Engine control harness, near T/O to C177
S157	Engine control harness, near T/O to C187
S158	Engine control harness, near T/O to C131
S159	Engine control harness, near T/O to C113
S160	Engine control harness, near T/O to C183
S161	Engine control harness, near T/O to C119
S162	Engine control harness, near T/O to C134

S163	Dash to headlamp harness, near T/O to C190
S164	Dash to headlamp harness, near T/O to C193
S165	Dash to headlamp harness, near T/O to G103
S166	Dash to headlamp harness, near T/O to C192
S167	Engine control harness, in T/O to C166
S168	Engine control harness, in T/O to C116
S169	Engine control harness, in the T/O to C154
S170	Engine control harness, in T/O to C116
S171	Fuel charge harness, in T/O to C116
S172	Fuel charge harness, in T/O to C140
S173	Fuel charge harness
S174	Engine control harness, near T/O to C158
S179	Engine control harness, near T/O to C149
S200	Main wiring harness, near T/O to C210
S201	Main wiring harness, near T/O to C201
S202	Main wiring harness, near T/O to C212
S203	Main wiring harness, near T/O to C212
S204	Main wiring harness, near T/O to C212
S205	Main wiring harness, near T/O to C223
S206	Main wiring harness, near T/O to C223
S207	Main wiring harness, near T/O to C223
S208	Main wiring harness, near T/O to C223
S209	Main wiring harness, near T/O to C223
S210	Main wiring harness, near T/O to C233
S211	Main wiring harness, near T/O to C225
S212	Main wiring harness, near T/O to C225
S213	Main wiring harness, near T/O to C225
S214	Main wiring harness, in T/O to C228
S215	Main wiring harness, near T/O to C233
S216	Main wiring harness, near T/O to C233
S217	Main wiring harness, near T/O to C233
S218	Main wiring harness, near T/O to C233
S219	Main wiring harness, in T/O to C227
S220	Main wiring harness, near T/O to C223
S221	Lower Instrument Panel (I/P) harness, near T/O to C238
S222	Lower I/P harness, near T/O to C238
S223	Lower I/P harness, near T/O to C238
S224	Lower I/P harness, near T/O to C234
S225	Lower I/P harness, near T/O to C234
S226	Lower I/P harness, near T/O to C234
S227	Lower I/P harness, near T/O to C234
S228	Lower I/P harness, in T/O to C241
S229	Lower I/P harness, in T/O to C241
S230	Lower I/P harness, near T/O to C245
S231	Lower I/P harness, near T/O to G204
S232	Lower I/P harness, near T/O to G204
S233	Lower I/P harness, near T/O to G204
S234	Lower I/P harness, near T/O to C301
S235	Lower I/P harness, near T/O to C329
S236	Lower I/P harness, near T/O to C246
S237	Lower I/P harness, near T/O to C245
S238	Lower I/P harness, near T/O to G204
S239	Lower I/P harness, near T/O to G204
S240	Lower I/P harness, near T/O to C237
S241	Lower I/P harness, near T/O to C237
S242	Lower I/P harness, near T/O to C245
S243	Lower I/P harness, near T/O to C331
S244	Lower I/P harness, near T/O to C331
S245	Lower I/P harness, in T/O to I/P fuse panel
S246	Lower I/P harness, near T/O to C329
S247	Lower I/P harness, near T/O to C331
S248	Lower I/P harness, near T/O to C331
S249	Lower I/P harness, near T/O to C331
S250	Lower I/P harness, near T/O to C345
S251	Lower I/P harness, near T/O to G204

S252	Lower I/P harness, near T/O to G204
S253	Lower I/P harness, near T/O to G204
S254	Lower I/P harness, near T/O to G204
S255	Lower I/P harness, near T/O to C329
S256	Lower I/P harness, near T/O to C334
S257	Lower I/P harness, near T/O to C329
S258	Lower I/P harness, near T/O to C331
S259	Lower I/P harness, near T/O to C331
S260	Lower I/P harness, near T/O to C332
S261	Lower I/P harness, near T/O to C245
S262	Lower I/P harness, near T/O to C245
S263	Lower I/P harness, near T/O to C245
S264	Lower I/P harness, near T/O to C237
S265	Lower I/P harness, near T/O to C237
S266	Lower I/P harness, near T/O to C238
S267	Main wiring harness, near T/O to G200
S300	Rear harness, near T/O to C302
S301	Rear harness, near T/O to C302
S302	Rear harness, near T/O to C302
S303	Rear harness, near T/O to C300
S304	Rear harness, near T/O to C300
S305	Rear harness, near T/O to C300
S306	Rear harness, near T/O to C402
S307	Fuel tank harness, near T/O to C347
S308	Fuel tank harness, near T/O to C104
S309	Fuel tank harness, near T/O to C104
S310	Fuel tank harness, near T/O to C101
S311	Interior harness, in T/O to C300
S312	Interior harness, in T/O to C300
S313	Interior harness, in T/O to C319
S314	Interior lamp harness, near T/O to C318
S315	Seat control jumper harness, near T/O to C338
S400	Auxiliary blower motor harness, near T/O to C403
S401	Auxiliary blower motor harness, in T/O to C402
S402	Rear harness, near T/O to C412
S403	Rear harness, near T/O to C411
S404	Rear harness, near T/O to C411
S405	Rear harness, near T/O to C411
S406	Rear harness, near T/O to C407
S500	Left front door, near T/O to window motor
S501	Left front door harness, in T/O to C500
S502	Left front door harness, in T/O to C501
S503	Left front door harness, near T/O to C501
S504	Left front door, near T/O to C507
S505	Left front door, near T/O to C505
S600	Right front door harness, near T/O to C601
S1007	Transmission control harness, near T/O to C115