




Accelerator Pedal Position Sensor: Locations



View 151-20 (Instrument Panel)



View 151-22 (Instrument Panel Harness - Stripped Chassis)



View 151-26 (Floor)