

Transfer Case: Connector Views

**C201 (BLACK)
TRANSFER CASE ASSEMBLY**

PIN	CIRCUIT	CIRCUIT FUNCTION
1	770 (W)	Contact Plate B
2	—	NOT USED
3	—	NOT USED
4	—	NOT USED
5	771 (P/Y)	Contact Plate A
6	—	NOT USED
7	—	NOT USED
8	—	NOT USED
9	764 (BR/W)	Contact Plate C
10	762 (Y/W)	Contact Plate Ground Return
11	—	NOT USED
12	—	NOT USED
13	763 (O/W)	Contact Plate D
14	778 (O)	Shift Relay to Motor H2L
15	777 (Y)	Shift Relay to Motor L2H
16	779 (BR)	Shift Relay to Electronic Clutch

Transfer Case Assembly

**C260
TRANSFER CASE ASSEMBLY**

PIN	CIRCUIT	CIRCUIT FUNCTION
1	779 BR	Transfer Case Power Feed
2	—	NOT USED
3	—	NOT USED
4	—	NOT USED

Transfer Case Assembly